


# DDJ-RB

## List of MIDI messages



【MIDI channel assignment】  
MIDI channel is defined as shown below.  
0x9\* :Note \* : value of channel No.(n/m/p)  
0xB\* :Control Change(CC)

| Channel Category        | MIDI Channel | *(Hex) |
|-------------------------|--------------|--------|
| DECK1                   | 1            | n=0    |
| DECK2                   | 2            | n=1    |
| FX DECK1                | 5            | m=4    |
| FX DECK2                | 6            | m=5    |
| Browser,Global Section  | 7            | m=6    |
| PERFORMANCE PAD (DECK1) | 8            | p=7    |
| PERFORMANCE PAD (DECK2) | 9            | p=8    |

As a reference for MIDI assign, MIDI message sent from buttons and knobs of this controller are listed in decimal numbers and English scale. Please utilize this reference depending on the notation of your MIDI compatible software.

NOTE is a term used for MIDI to express that a key of a keyboard or a piano is pressed or your finger is released from it. CC is an abbreviation of "Control Change". Control Change is a kind of MIDI message used to communicate many kinds of control information such as sound quality and volume level. English scale uses alphabetical letters of C, D, E, F, G, A and B as well as # to indicate half tone.

| Group   | Part No.     | User Interface  |         |        | MIDI assign reference        |                    |         |                          | MIDI-IN (to computer) |              |              | MIDI-OUT (from computer) |              |              | Detail (Data2) |   |
|---------|--------------|-----------------|---------|--------|------------------------------|--------------------|---------|--------------------------|-----------------------|--------------|--------------|--------------------------|--------------|--------------|----------------|---|
|         |              | UI name         | Trigger | +SHIFT | Condition (mode)             | MIDI Channel (Dec) | NOTE/CC | MIDI Data (Data 1) (Dec) | (English scale)       | Status (Hex) | Data 1 (Hex) | Data 2 (Hex)             | Status (Hex) | Data 1 (Hex) |                | Data 2 (Hex)  |
| BROWSER | B1           | Rotary selector | rotate  |        |                              | 7                  | CC      | 64                       | -                     | B6           | 40           | hh                       |              |              |                | Difference count value from when previous operated<br>Turn clockwise: 0x01-0x1E(max)<br>(1-30clicks/40msec)<br>Turn counterclockwise: 0x7F-0x62(max)<br>(1-30clicks/40msec) |
|         |              |                 | press   | +SHIFT |                              | 7                  | CC      | 100                      | -                     | B6           | 64           | hh                       |              |              |                |   |
|         | B3-L<br>B3-R | LOAD            | press   | +SHIFT | deck1 selected on left deck  | 7                  | NOTE    | 70                       | A#4                   | 96           | 46           | hh                       |              |              |                | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F  |
|         |              |                 | press   |        | deck2 selected on right deck | 7                  | NOTE    | 88                       | E6                    | 96           | 58           | hh                       |              |              |                | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F  |
|         |              |                 | press   | +SHIFT |                              | 7                  | NOTE    | 71                       | B4                    | 96           | 47           | hh                       |              |              |                | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F  |

| Group | Part No.       | User Interface   |         |            | MIDI assign reference |                    |         |                          | MIDI-IN (to computer) |              |              | MIDI-OUT (from computer) |              |              | Detail (Data2) |   |   |
|-------|----------------|------------------|---------|------------|-----------------------|--------------------|---------|--------------------------|-----------------------|--------------|--------------|--------------------------|--------------|--------------|----------------|---|---|
|       |                | UI name          | Trigger | +SHIFT     | Condition (mode)      | MIDI Channel (Dec) | NOTE/CC | MIDI Data (Data 1) (Dec) | (English scale)       | Status (Hex) | Data 1 (Hex) | Data 2 (Hex)             | Status (Hex) | Data 1 (Hex) |                | Data 2 (Hex)  |   |
| DECK  | D1-L<br>D1-R   | PLAY/PAUSE       | press   | +SHIFT     |                       | 1/2                | NOTE    | 11                       | B-1                   | 9n           | 0B           | hh                       |              |              |                | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F  |   |
|       | D2-L<br>D2-R   | CUE              | press   | +SHIFT     |                       | 1/2                | NOTE    | 12                       | C0                    | 9n           | 0C           | hh                       |              |              |                | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F  |   |
|       | D3-L<br>D3-R   | JOG (Platter)    | rotate  |            |                       | Vinyl On           | 1/2     | CC                       | 34                    | -            | Bn           | 22                       | hh           |              |                |   | Difference count value from when previous operated<br>When turned clockwise: Increases from 0x41<br>When turned counterclockwise: Decreases from 0x3F |
|       |                |                  | rotate  | +SHIFT     | Vinyl Off             | 1/2                | CC      | 35                       | -                     | Bn           | 23           | hh                       |              |              |                |   |   |
|       |                | JOG (Wheel side) | touch   | +SHIFT     |                       | 1/2                | NOTE    | 54                       | F#3                   | 9n           | 36           | hh                       |              |              |                |   | OFF=0x00, ON=0x7F   |
|       |                |                  | rotate  | +SHIFT     |                       | 1/2                | NOTE    | 103                      | G7                    | 9n           | 67           | hh                       |              |              |                |   | OFF=0x00, ON=0x7F   |
|       | D4-L<br>D4-R   | TEMPO            | slide   | +SHIFT     |                       | 1/2                | CC      | 0                        | -                     | Bn           | 00           | MSB<br>LSB               |              |              |                | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)<br>"." side : Min(MSB:0x00 LSB:0x00)<br>"+" side : Max(MSB:0x7F LSB:0x7F) |   |
|       | D9-L<br>D9-R   | SYNC             | press   | +SHIFT     |                       | 1/2                | NOTE    | 88                       | E6                    | 9n           | 58           | hh                       |              |              |                |   | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F  |
|       |                |                  | press   |            |                       | 1/2                | NOTE    | 92                       | G#6                   | 9n           | 5C           | hh                       |              |              |                |   | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F  |
|       | D13-L<br>D13-R | LOOP IN          | press   | +SHIFT     |                       | 1/2                | NOTE    | 16                       | E0                    | 9n           | 10           | hh                       |              |              |                |   | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F  |
|       |                |                  | press   | long press |                       | 1/2                | NOTE    | 76                       | E5                    | 9n           | 4C           | hh                       |              |              |                |   | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F  |
|       | D14-L<br>D14-R | LOOP OUT         | press   | +SHIFT     |                       | 1/2                | NOTE    | 69                       | A4                    | 9n           | 45           | hh                       |              |              |                |   | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F  |
|       | D22-L<br>D22-R | SHIFT            | press   |            |                       | 1/2                | NOTE    | 17                       | F0                    | 9n           | 11           | hh                       |              |              |                |   | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F  |

| Group | Part No.                           | User Interface                       |         |        |                  | MIDI assign reference |         |                    |     | MIDI-IN (to computer) |              |              | MIDI-OUT (from computer) |              |              | Detail (Data2)   |
|-------|------------------------------------|--------------------------------------|---------|--------|------------------|-----------------------|---------|--------------------|-----|-----------------------|--------------|--------------|--------------------------|--------------|--------------|--|
|       |                                    | UI name                              | Trigger | +SHIFT | Condition (mode) | MIDI Channel (Dec)    | NOTE/CC | MIDI Data (Data 1) |     | Status (Hex)          | Data 1 (Hex) | Data 2 (Hex) | Status (Hex)             | Data 1 (Hex) | Data 2 (Hex) |  |
| MIXER | M1                                 | CROSSFADER                           | slide   | +SHIFT |                  | 7                     | CC      | 31<br>63           | -   | B6                    | 1F<br>3F     | MSB<br>LSB   |                          |              |              | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)<br>Min at left side, Max at right side   |
|       | M2-1<br>M2-2<br>M2-3<br>M2-4       | CH FADER                             | slide   | +SHIFT |                  | 1/2                   | CC      | 19<br>51           | -   | Bn                    | 13<br>33     | MSB<br>LSB   |                          |              |              | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)<br>Min at bottom end, Max at top end   |
|       | M1<br>M2-1<br>M2-2<br>M2-3<br>M2-4 | CROSS FADER / CH Fader (Fader Start) | slide   | +SHIFT | Zero → not Zero  | 1/2                   | NOTE    | 102                | F#7 | 9n                    | 66           | hh           |                          |              |              | PLAY message only for CH fader start<br>OFF=0x00, ON=0x7F  |
|       |                                    |                                      |         | +SHIFT | Not Zero → Zero  | 1/2                   | NOTE    | 82                 | A#6 | 9n                    | 52           | hh           |                          |              |              | CUE message only for CH fader start<br>OFF=0x00, ON=0x7F   |
|       | M3-1<br>M3-2<br>M3-3               | GAIN (TRIM)                          | rotate  | +SHIFT |                  | 1/2                   | CC      | 4<br>36            | -   | Bn                    | 04<br>24     | MSB<br>LSB   |                          |              |              | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)<br>When turned fully counterclockwise: Min<br>When turned fully clockwise: Max |
|       | M4-1<br>M4-2<br>M4-3               | EQ HIGH                              | rotate  | +SHIFT |                  | 1/2                   | CC      | 7<br>39            | -   | Bn                    | 07<br>27     | MSB<br>LSB   |                          |              |              | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)<br>When turned fully counterclockwise: Min<br>When turned fully clockwise: Max |
|       | M5-1<br>M5-2<br>M5-3               | EQ MID                               | rotate  | +SHIFT |                  | 1/2                   | CC      | 11<br>43           | -   | Bn                    | 0B<br>2B     | MSB<br>LSB   |                          |              |              | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)<br>When turned fully counterclockwise: Min<br>When turned fully clockwise: Max |
|       | M6-1<br>M6-2<br>M6-3               | EQ LOW                               | rotate  | +SHIFT |                  | 1/2                   | CC      | 15<br>47           | -   | Bn                    | 0F<br>2F     | MSB<br>LSB   |                          |              |              | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)<br>When turned fully counterclockwise: Min<br>When turned fully clockwise: Max |
|       | M7-1<br>M7-2                       | CUE (Headphone)                      | press   | +SHIFT |                  | 1/2                   | NOTE    | 84                 | C6  | 9n                    | 54           | hh           |                          |              |              | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|       |                                    |                                      |         | +SHIFT |                  | 1/2                   | NOTE    | 104                | G#7 | 9n                    | 68           | hh           |                          |              |              | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|       | M8                                 | MASTER LEVEL                         | rotate  |        |                  | 7                     | CC      | 8<br>40            | -   | B6                    | 08<br>28     | MSB<br>LSB   |                          |              |              | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)  |
|       | M13-1<br>M13-2                     | CH LEVEL                             | -       |        |                  |                       |         |                    |     |                       |              |              | Bn                       | 02           | hh           |  |
|       | M14                                | HEADPHONES MASTER                    | press   | +SHIFT |                  | 7                     | NOTE    | 91                 | G6  | 96                    | 5B           | hh           |                          |              |              | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|       |                                    |                                      |         | +SHIFT |                  | 7                     | NOTE    | 120                | C9  | 96                    | 78           | hh           |                          |              |              | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|       | M15                                | HEADPHONES VOL                       | rotate  |        |                  | 7                     | CC      | 13<br>45           | -   | B6                    | 0D<br>2D     | MSB<br>LSB   |                          |              |              | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)  |

| Group  | Part No.    | User Interface   |         |        |                             | MIDI assign reference |         |                    |     | MIDI-IN (to computer) |              |              | MIDI-OUT (from computer) |              |  | Detail (Data2)   |
|--------|-------------|------------------|---------|--------|-----------------------------|-----------------------|---------|--------------------|-----|-----------------------|--------------|--------------|--------------------------|--------------|--|--|
|        |             | UI name          | Trigger | +SHIFT | Condition (mode)            | MIDI Channel (Dec)    | NOTE/CC | MIDI Data (Data 1) |     | Status (Hex)          | Data 1 (Hex) | Data 2 (Hex) | Status (Hex)             | Data 1 (Hex) | Data 2 (Hex)                           |  |
| EFFECT | E1-L        | FX1-1            | rotate  | +SHIFT |                             | 5                     | CC      | 2<br>34            | -   | B4                    | 02<br>22     | MSB<br>LSB   |                          |              |  | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)<br>When turned fully counterclockwise: Min<br>When turned fully clockwise: Max |
|        |             |                  |         | +SHIFT |                             | 5                     | CC      | 18<br>50           | -   | B4                    | 12<br>32     | MSB<br>LSB   |                          |              |  | 0x00~0x7F<br>When turned fully counterclockwise: 0x00<br>When turned fully clockwise: 0x7F                                   |
|        | E1-R        | FX2-1            | rotate  | +SHIFT |                             | 6                     | CC      | 2<br>34            | -   | B5                    | 02<br>22     | MSB<br>LSB   |                          |              |  | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)<br>When turned fully counterclockwise: Min<br>When turned fully clockwise: Max |
|        |             |                  |         | +SHIFT |                             | 6                     | CC      | 18<br>50           | -   | B5                    | 12<br>32     | MSB<br>LSB   |                          |              |  | 0x00~0x7F<br>When turned fully counterclockwise: 0x00<br>When turned fully clockwise: 0x7F                                   |
|        | E5-L        | FX1-1 ON         | press   | +SHIFT |                             | 5                     | NOTE    | 71                 | B4  | 94                    | 47           | hh           |                          |              |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|        |             |                  |         | +SHIFT |                             | 5                     | NOTE    | 99                 | D#7 | 94                    | 63           | hh           |                          |              |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|        | E5-R        | FX2-1 ON         | press   | +SHIFT |                             | 6                     | NOTE    | 71                 | B4  | 95                    | 47           | hh           |                          |              |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|        |             |                  |         | +SHIFT |                             | 6                     | NOTE    | 99                 | D#7 | 95                    | 63           | hh           |                          |              |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|        | E11-1       | Filter Parameter | rotate  |        | deck1 selected on left deck | 7                     | CC      | 23<br>55           | -   | B6                    | 17<br>37     | MSB<br>LSB   |                          |              |  | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)<br>When turned fully counterclockwise: Min<br>When turned fully clockwise: Max |
|        | E11-2       |                  | rotate  |        | deck2 selected on left deck | 7                     | CC      | 24<br>56           | -   | B6                    | 18<br>38     | MSB<br>LSB   |                          |              |  | Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)<br>When turned fully counterclockwise: Min<br>When turned fully clockwise: Max |
|        | E23-L       | FX1 BEAT DOWN    | press   | +SHIFT |                             | 5                     | NOTE    | 74                 | D5  | 94                    | 4A           | hh           |                          |              |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|        |             |                  |         | +SHIFT |                             | 5                     | NOTE    | 102                | F#7 | 94                    | 66           | hh           |                          |              |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|        | E23-R       | FX2 BEAT DOWN    | press   | +SHIFT |                             | 6                     | NOTE    | 74                 | D5  | 95                    | 4A           | hh           |                          |              |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|        |             |                  |         | +SHIFT |                             | 6                     | NOTE    | 102                | F#7 | 95                    | 66           | hh           |                          |              |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|        | E24-L       | FX1 BEAT UP      | press   | +SHIFT |                             | 5                     | NOTE    | 75                 | D#5 | 94                    | 4B           | hh           |                          |              |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F   |
|        |             |                  | +SHIFT  |        | 5                           | NOTE                  | 107     | B7                 | 94  | 6B                    | hh           |              |                          |              | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |
| E24-R  | FX2 BEAT UP | press            | +SHIFT  |        | 6                           | NOTE                  | 75      | D#5                | 95  | 4B                    | hh           |              |                          |              | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |
|        |             |                  | +SHIFT  |        | 6                           | NOTE                  | 107     | B7                 | 95  | 6B                    | hh           |              |                          |              | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |

| Group          | Part No.              | User Interface        |         |                     |                     | MIDI assign reference |         |                    |      | MIDI-IN (to computer) |              |              | MIDI-OUT (from computer) |  |  | Detail (Data2)                         |  |  |
|----------------|-----------------------|-----------------------|---------|---------------------|---------------------|-----------------------|---------|--------------------|------|-----------------------|--------------|--------------|--------------------------|--|--|--|--|--|
|                |                       | UI name               | Trigger | +SHIFT              | Condition (mode)    | MIDI Channel (Dec)    | NOTE/CC | MIDI Data (Data 1) |      | Status (Hex)          | Data 1 (Hex) | Data 2 (Hex) | Status (Hex)             | Data 1 (Hex)                           | Data 2 (Hex)                           |  |  |  |
| MULTI FUNCTION | S1-L<br>S1-R          | PERFORMANCE PAD 1     | press   | +SHIFT              | in HOT CUE mode     | 8/9                   | NOTE    | 0                  | C-1  | 9p                    | 00           | hh           |                          |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |  |
|                |                       |                       |         |                     | in PAD FX1 mode     | 8/9                   | NOTE    | 8                  | G#-1 | 9p                    | 08           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         | +SHIFT              |                     | 8/9                   | NOTE    | 16                 | E0   | 9p                    | 10           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         |                     | in SLICER mode      | 8/9                   | NOTE    | 24                 | C1   | 9p                    | 18           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         | +SHIFT              |                     | 8/9                   | NOTE    | 32                 | G#1  | 9p                    | 20           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         |                     | in SAMPLER mode     | 8/9                   | NOTE    | 40                 | E2   | 9p                    | 28           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         | +SHIFT              |                     | 8/9                   | NOTE    | 48                 | C3   | 9p                    | 30           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         |                     | in BEAT JUMP mode   | 8/9                   | NOTE    | 56                 | G#3  | 9p                    | 38           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         | +SHIFT              |                     | 8/9                   | NOTE    | 64                 | E4   | 9p                    | 40           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         |                     | in PAD FX2 mode     | 8/9                   | NOTE    | 72                 | C5   | 9p                    | 48           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         | +SHIFT              |                     | 8/9                   | NOTE    | 80                 | G#5  | 9p                    | 50           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         |                     | in SLICER LOOP mode | 8/9                   | NOTE    | 88                 | E6   | 9p                    | 58           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                | +SHIFT                |                       | 8/9     | NOTE                | 96                  | C7                    | 9p      | 60                 | hh   |                       |              |              |                          |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |  |  |
|                |                       | in SEQUENCE CALL mode | 8/9     | NOTE                | 104                 | G#7                   | 9p      | 68                 | hh   |                       |              |              |                          |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |  |  |
|                | +SHIFT                |                       | 8/9     | NOTE                | 112                 | E8                    | 9p      | 70                 | hh   |                       |              |              |                          |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |  |  |
|                |                       |                       | 8/9     | NOTE                | 120                 | C9                    | 9p      | 78                 | hh   |                       |              |              |                          |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |  |  |
|                | S2-L<br>S2-R          | PERFORMANCE PAD 2     | press   | +SHIFT              | in HOT CUE mode     | 8/9                   | NOTE    | 1                  | C#-1 | 9p                    | 01           | hh           |                          |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |  |
|                |                       |                       |         |                     | in PAD FX1 mode     | 8/9                   | NOTE    | 9                  | A-1  | 9p                    | 09           | hh           |                          |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |
|                |                       |                       |         | +SHIFT              |                     | 8/9                   | NOTE    | 17                 | F0   | 9p                    | 11           | hh           |                          |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |
|                |                       |                       |         |                     | in SLICER mode      | 8/9                   | NOTE    | 25                 | C#1  | 9p                    | 19           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         | +SHIFT              |                     | 8/9                   | NOTE    | 33                 | A1   | 9p                    | 21           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         |                     | in SAMPLER mode     | 8/9                   | NOTE    | 41                 | F2   | 9p                    | 29           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         | +SHIFT              |                     | 8/9                   | NOTE    | 49                 | C#3  | 9p                    | 31           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
|                |                       |                       |         |                     | in BEAT JUMP mode   | 8/9                   | NOTE    | 57                 | A3   | 9p                    | 39           | hh           |                          |  |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |
| +SHIFT         |                       |                       |         |                     | 8/9                 | NOTE                  | 65      | F4                 | 9p   | 41                    | hh           |              |                          |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |
|                |                       |                       |         | in PAD FX2 mode     | 8/9                 | NOTE                  | 73      | C#5                | 9p   | 49                    | hh           |              |                          |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |
| +SHIFT         |                       |                       |         |                     | 8/9                 | NOTE                  | 81      | A5                 | 9p   | 51                    | hh           |              |                          |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |
|                |                       |                       |         | in SLICER LOOP mode | 8/9                 | NOTE                  | 89      | F6                 | 9p   | 59                    | hh           |              |                          |  |  |  | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |
| +SHIFT         |                       | 8/9                   | NOTE    | 97                  | C#7                 | 9p                    | 61      | hh                 |      |                       |              |              |                          | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |  |  |  |
|                | in SEQUENCE CALL mode | 8/9                   | NOTE    | 105                 | A7                  | 9p                    | 69      | hh                 |      |                       |              |              |                          | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |  |  |  |
| +SHIFT         |                       | 8/9                   | NOTE    | 113                 | F8                  | 9p                    | 71      | hh                 |      |                       |              |              |                          | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |  |  |  |
|                |                       | 8/9                   | NOTE    | 121                 | C#9                 | 9p                    | 79      | hh                 |      |                       |              |              |                          | ← Same as MIDI-IN<br>OFF=0x00, ON=0x7F |  |  |  |  |

