

DDJ-SX3

List of MIDI messages version 1.00



.UI function& MIDI map

【MIDI channel assignment】

MIDI channel is defined as shown below.

0x9* :Note

* : value of channel No.(n/m/p)

0xB* :Control Change(CC)

Channel Category	MIDI Channel	"(Hex)
DECK1	1	m=0
DECK2	2	m=1
DECK3	3	m=2
DECK4	4	m=3
FX DECK1/DECK3	5	m=4
FX DECK2/DECK4	6	m=5
Browser,Global Section	7	m=6
PERFORMANCE PAD (DECK1)	8	p=7
PERFORMANCE PAD (DECK2)	9	p=8
PERFORMANCE PAD (DECK3)	10	p=9
PERFORMANCE PAD (DECK4)	11	p=A

As a reference for MIDI assign, MIDI message sent from buttons and knobs of this controller are listed in decimal numbers and English scale

Please utilize this reference depending on the notation of your MIDI compatible software.

NOTE is a term used for MIDI to express that a key of a keyboard or a piano is pressed or your finger is released from it.

CC is an abbreviation of "Control Change". Control Change is a kind of MIDI message used to communicate many kinds of control information such as sound quality and volume level.

English scale uses alphabetical letters of C, D, E, F, G, A and B as well as # to indicate half-tone

Group	Fig.	User interface				MIDI assign reference			MIDI-IN (to computer)			MIDI-OUT (from computer)			Details (Data 2)	
		UI name	+SHIFT	Trigger	Condition (mode)	MIDI Channel (Dec)	NOTE / CC	MIDI Data (Data 1) (Dec)	(English scale)	Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	Status (Hex)	Data 1 (Hex)		Data 2 (Hex)
1.DECK																
1	PLAY/PAUSE			press		1/2/3/4	NOTE	11	B-1	9n	0B	hh		~ Same as MIDI-IN	OFF=0x00, ON=0x7F	
		+SHIFT				1/2/3/4	NOTE	71	B4	9n	47	hh		~ Same as MIDI-IN	OFF=0x00, ON=0x7F	
2	CUE			press		1/2/3/4	NOTE	12	C0	9n	0C	hh		~ Same as MIDI-IN	OFF=0x00, ON=0x7F	
		+SHIFT				1/2/3/4	NOTE	72	C5	9n	48	hh		~ Same as MIDI-IN	OFF=0x00, ON=0x7F	
3	SYNC			press		1/2/3/4	NOTE	93	A6	9n	5D	hh		~ Same as MIDI-IN	OFF=0x00, ON=0x7F	
		+SHIFT				1/2/3/4	NOTE	92	G#6	9n	5C	hh		~ Same as MIDI-IN	OFF=0x00, ON=0x7F	
4	SHIFT			press		1/2/3/4	NOTE	63	D#4	9n	3F	hh				
						1/2/3/4	NOTE	53	F3	9n	35	hh		~ Same as MIDI-IN	OFF=0x00, ON=0x7F	
5	QUANTIZE			press		1/2/3/4	NOTE	57	A3	9n	39	hh		~ Same as MIDI-IN	OFF=0x00, ON=0x7F	
		+SHIFT				1/2/3/4	NOTE	57	A3	9n	39	hh		~ Same as MIDI-IN	OFF=0x00, ON=0x7F	
6	JOG (Platter)			rotate	Vinyl On	1/2/3/4	CC	34	-	Bn	22	hh			Difference count value from when previous operated When turned clockwise: Increases from 0x41 When turned counterclockwise: Decreases from 0x3F	
					Vinyl Off	1/2/3/4	CC	35	-	Bn	23	hh				
		+SHIFT				1/2/3/4	CC	31	-	Bn	1F	hh				
						1/2/3/4	NOTE	54	F#3	9n	36	hh				
	+SHIFT	touch				1/2/3/4	NOTE	103	G7	9n	67	hh			OFF=0x00, ON=0x7F	
							1/2/3/4	NOTE	103	G7	9n	67	hh			OFF=0x00, ON=0x7F
JOG (Wheel side)			rotate		1/2/3/4	CC	33	-	Bn	21	hh			Difference count value from when previous operated When turned clockwise: Increases from 0x41 When turned counterclockwise: Decreases from 0x3F		
	+SHIFT				1/2/3/4	CC	38	-	Bn	26	hh					

3. EFFECT	7	NEEDLE SEARCH		touch		1/2/3/4	CC	3	-	Bn	03	hh				OFF ~ 0x00, ON ~ 0x00 - 0x7F 0 at left edge, 127 at right edge
						1/2/3/4	NOTE	67	G4	9n	43	hh				OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	CC	40	-	Bn	28	hh				OFF ~ 0x00, ON ~ 0x00 - 0x7F 0x00 at left edge, 0x7F at right edge
						1/2/3/4	NOTE	68	G#4	9n	44	hh				OFF~0x00, ON~0x7F
	8	CENSOR (REV)		press		1/2/3/4	NOTE	21	A0	9n	15	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	56	G#3	9n	38	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	9	KEY UP/SYNC		press		1/2/3/4	NOTE	121	C#9	9n	79	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	100	E7	9n	64	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	10	KEY DOWN /RESET		press		1/2/3/4	NOTE	10	A#-1	9n	0A	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	101	F7	9n	65	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	11 12 13 14	DECK 1/2/3/4		press		1/2/3/4	NOTE	114	F#8	9n	72	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F LED are lit by itself without MIDI
			+SHIFT			1/2/3/4	NOTE	115	G8	9n	73	hh				
	15	SLIP		press		1/2/3/4	NOTE	64	E4	9n	40	hh				OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	23	B0	9n	17	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	16	KEYLOCK		press		1/2/3/4	NOTE	26	D1	9n	1A	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	96	C7	9n	60	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	17	TEMPO		slide		1/2/3/4	NOTE	28	E1	9n	1C	hh				OFF~0x00, ON~0x7F
						1/2/3/4	CC	0	-	Bn	00	MSB				Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F)
						1/2/3/4	CC	32	-	Bn	20	LSB				"-" side : 0
			+SHIFT			1/2/3/4	CC	5	-	Bn	05	MSB				"+" side : 16383
	18	SLOT		press		1/2/3/4	NOTE	73	C#5	9n	49	hh				OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	89	F6	9n	59	hh				OFF~0x00, ON~0x7F
	19	REC		press		1/2/3/4	NOTE	74	D5	9n	4A	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	90	F#6	9n	5A	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	20	START		press		1/2/3/4	NOTE	75	D#5	9n	4B	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	91	G6	9n	5B	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	21	AUTO LOOP		press		1/2/3/4	NOTE	20	G#0	9n	14	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	80	G#5	9n	50	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	22	LOOP 1/2x		press		1/2/3/4	NOTE	18	F#0	9n	12	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	97	C#7	9n	61	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	23	LOOP 2x		press		1/2/3/4	NOTE	19	G0	9n	13	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	98	D7	9n	62	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	24	LOOP IN		press		1/2/3/4	NOTE	16	E0	9n	10	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			1/2/3/4	NOTE	76	E5	9n	4C	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			long press			1/2/3/4	NOTE	69	A4	9n	45	hh				OFF~0x00, ON~0x7F
						1/2/3/4	NOTE	17	F0	9n	11	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	25	LOOP OUT	+SHIFT			1/2/3/4	NOTE	77	F5	9n	4D	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
3. EFFECT	1	FX1-1		rotate		5	CC	2	-	B4	02	MSB				Min(MSB:0x00 LSB:0x00)~Max(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
						5	CC	34	-	B4	22	LSB				
			+SHIFT			5	CC	18	-	B4	12	MSB				
						5	CC	50	-	B4	32	LSB				
	2	FX1-2		rotate		6	CC	2	-	B5	02	MSB				
						6	CC	34	-	B5	22	LSB				
						6	CC	18	-	B5	12	MSB				
			+SHIFT			6	CC	50	-	B5	32	LSB				
	3	FX1-3		rotate		5	CC	4	-	B4	04	MSB				Difference count value from when previous operated Turn clockwise: 1 - 30 , Turn counterclockwise: 127 - 98
						5	CC	36	-	B4	24	LSB				
						5	CC	20	-	B4	14	MSB				
			+SHIFT			5	CC	52	-	B4	34	LSB				
	4	FX2-2		rotate		6	CC	4	-	B5	04	MSB				
						6	CC	36	-	B5	24	LSB				
						6	CC	20	-	B5	14	MSB				
			+SHIFT			6	CC	52	-	B5	34	LSB				
	5	FX1-3		rotate		5	CC	6	-	B4	06	MSB				Difference count value from when previous operated Turn clockwise: 1 - 30 , Turn counterclockwise: 127 - 98
						5	CC	38	-	B4	26	LSB				
						5	CC	22	-	B4	16	MSB				
			+SHIFT			5	CC	54	-	B4	36	LSB				
	6	FX2-3		rotate		6	CC	6	-	B5	06	MSB				
						6	CC	38	-	B5	26	LSB				
						6	CC	22	-	B5	16	MSB				
			+SHIFT			6	CC	54	-	B5	36	LSB				
	7	FX1 BEAT		rotate		5	CC	0	-	B4	00	hh				Difference count value from when previous operated Turn clockwise: 1 - 30 , Turn counterclockwise: 127 - 98
			+SHIFT			5	CC	16	-	B4	10	hh				
						5	NOTE	67	G4	94	43	hh				
						5	NOTE	64	E4	94	40	hh				
	8	FX2 BEAT		rotate		6	CC	0	-	B5	00	hh				
			+SHIFT			6	CC	16	-	B5	10	hh				
						6	NOTE	67	G4	95	43	hh				
						6	NOTE	64	E4	95	40	hh				
	9	FX1-1 ON		press		5	NOTE	71	B4	94	47	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			5	NOTE	99	D#7	94	63	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
						6	NOTE	71	B4	95	47	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
						6	NOTE	99	D#7	95	63	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	10	FX2-1 ON		press		5	NOTE	72	C5	94	48	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			5	NOTE	100	E7	94	64	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
						6	NOTE	72	C5	95	48	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
						6	NOTE	100	E7	95	64	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	11	FX1-2 ON		press		5	NOTE	73	C#5	94	49	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			5	NOTE	101	F7	94	65	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
						6	NOTE	73	C#5	95	49	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
						6	NOTE	101	F7	95	65	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	12	FX2-2 ON		press		7	NOTE	80	G#5	96	50	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			7	NOTE	82	A#5	96	52	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			long press			7	NOTE	90	F#6	96	5A	hh				OFF~0x00, ON~0x7F
						7	NOTE	81	A5	96	51	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
	13	FX1 Assign		press		7	NOTE	83	B5	96	53	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			7	NOTE	84	C6	96	54	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
						7	NOTE	86	D6	96	56	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			long press			7	NOTE	91	G6	96	5B	hh				OFF~0x00, ON~0x7F
	14	FX2 Assign		press		7	NOTE	85	C#6	96	55	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F
			+SHIFT			7	NOTE	87	D#6	96	57	hh			~ Same as MIDI-IN	OFF~0x00, ON~0x7F

3. MIXER																
1	USB A, PHONO/LINE, USB B	slide	Switch to USB A	1/2	NOTE	85	C#6	90/91	55	7F						
				1/2	NOTE	86	D6	90/91	56	0						
			Switch to PHONO/LINE	1/2	NOTE	85/87	C#6/D#6	90/91	55/57	0						
			Switch to USB B	1/2	NOTE	87	D#6	90/91	57	7F						
2	USB A, LINE, MIC, USB B	slide	Switch to USB A	3/4	NOTE	85	C#6	92/93	55	7F						
				3/4	NOTE	86	D6	92/93	56	0						
			Switch to LINE	3/4	NOTE	86	D6	92/93	56	7F						
				3/4	NOTE	85/87	C#6/D#6	92/93	55/57	0						
			Switch to MIC	3/4	NOTE	87	D#6	92/93	57	7F						
				3/4	NOTE	86/88	D6/E6	92/93	56/58	0						
			Switch to USB B	3/4	NOTE	88	E6	92/93	58	7F						
				3/4	NOTE	87	D#6	92/93	57	0						
3	TRIM	rotate		1/2/3/4	CC	4	-	Bn	04	MSB						
				1/2/3/4	CC	36	-	Bn	24	LSB						
4	EQ HIGH	rotate		1/2/3/4	CC	7	-	Bn	07	MSB						
				1/2/3/4	CC	39	-	Bn	27	LSB						
	EQ MID	rotate		1/2/3/4	CC	11	-	Bn	0B	MSB						
				1/2/3/4	CC	43	-	Bn	2B	LSB						
5	EQ LOW	rotate		1/2/3/4	CC	15	-	Bn	0F	MSB						
				1/2/3/4	CC	47	-	Bn	2F	LSB						
5	CH LEVEL INDICATOR	-									Bn	02	hh			Use when INPUT Selector is "USB A" or "USB B"
6	COLOR	rotate	SOUND COLOR FX ch1	7	CC	23	-	B6	17	MSB						
				7	CC	55	-	B6	37	LSB						
			SOUND COLOR FX ch2	7	CC	24	-	B6	18	MSB						
				7	CC	56	-	B6	38	LSB						
7	SOUND COLOR FX	rotate	SOUND COLOR FX ch3	7	CC	25	-	B6	19	MSB						
				7	CC	57	-	B6	39	LSB						
			SOUND COLOR FX ch4	7	CC	26	-	B6	1A	MSB						
				7	CC	58	-	B6	3A	LSB						
7	HEADPHONES CUE			1/2/3/4	NOTE	84	C6	9n	54	hh						
8	/MIC REVERS	+SHIFT	press													
9	CH FADER	slide		1/2/3/4	NOTE	104	G#7	9n	68	hh						
				1/2/3/4	CC	19	-	Bn	13	MSB						
				1/2/3/4	CC	51	-	Bn	33	LSB						
			Zero → not Zero	1/2/3/4	NOTE	102	F#7	9n	66	hh						
10	CRF ASSIGN	slide		1/2/3/4	NOTE	22	A#0	9n	16	7F						
				1/2/3/4	NOTE	29	F1	9n	1D	00						
			Switch to THRU	1/2/3/4	NOTE	22/24	A#0/C1	9n	16/18	00						
				1/2/3/4	NOTE	29	F1	9n	1D	7F						
11	CROSSFADER	slide		1/2/3/4	NOTE	24	C1	9n	18	7F						
				1/2/3/4	NOTE	29	F1	9n	1D	00						
				7	CC	31	-	B6	1F	MSB						
				7	CC	63	-	B6	3F	LSB						
12	MASTER LEVEL	rotate		1/2/3/4	NOTE	102	F#7	9n	66	hh						
				1/2/3/4	NOTE	82	A#5	9n	52	hh						
			Zero → not Zero	1/2/3/4	NOTE	102	F#7	9n	66	hh						
			Not Zero → Zero	1/2/3/4	NOTE	82	A#5	9n	52	hh						
12	MASTER LEVEL															
13	MASTER LEVEL INDICATOR	-														
14	SOUND COLOR FX	press	ECHO	7	NOTE	0	C-1	96	00	hh						
				7	NOTE	8	G#-1	96	08	hh						
			NOISE	7	NOTE	2	D-1	96	02	hh						
				7	NOTE	10	A#-1	96	0A	hh						
15	SOUND COLOR FX	press	JET	7	NOTE	3	D#-1	96	03	hh						
				7	NOTE	11	B-1	96	0B	hh						
			FILTER	7	NOTE	1	C#-1	96	01	hh						
				7	NOTE	9	A-1	96	09	hh						
16																
17																
18	MASTER CUE	+SHIFT	press													
19	BOOTH LEVEL		rotate													
20	SAMPLER VOLUME	rotate		7	CC	3	-	B6	03	MSB						
				7	CC	35	-	B6	23	LSB						
				7	CC	105	-	B6	69	hh						
21	CROSS F. CURVE	slide		7	NOTE	22	A#0	96	16	7F						
				7	NOTE	23	B0	96	17	00						
				7	NOTE	23	B0	96	17	7F						
				7	NOTE	22/24	A#0/C1	96	16/18	00						
22	HEADPHONES LEVEL	rotate		7	NOTE	24	C1	96	18	7F						
				7	NOTE	23	B0	96	17	00						
23	HEADPHONES MIX		rotate													
24	MIC3 LEVEL		rotate													
25	MIC3 ON/OFF Switch	slide	Switch to ON	7	NOTE	25	C#1	96	19	7F						
				7	NOTE	26	D1	96	1A	00						
			Switch to OFF	7	NOTE	26	D1	96	1A	7F						
				7	NOTE	25	C#1	96	19	00						
26	LINE / PHONO	slide	Switch to PHONO	1/2	NOTE	78	F#5	9n	4E	7F						
				1/2	NOTE	79	G5	9n	4F	00						
			Switch to LINE	1/2	NOTE	79	G5	9n	4F	7F						
				1/2	NOTE	78	F#5	9n	4E	00						

BROWSE																	
1	BROWSE	+SHIFT	rotate		7	CC	64	-	B6	40	hh						Difference count value from when previous operated Turn clockwise: 1 - 30, Turn counterclockwise: 127 - 98
			press		7	NOTE	65	F4	96	41	hh						
2	LOAD	+SHIFT			7	NOTE	66	F#4	96	42	hh						OFF=0x00, ON=0x7F
					7	NOTE	70	A#4	96	46	hh						OFF=0x00, ON=0x7F
2		+SHIFT			7	NOTE	88	E6	96	58	hh				- Same as MIDI-IN	OFF=0x00, ON=0x7F	
					7	NOTE	71	B4	96	47	hh					OFF=0x00, ON=0x7F	
2		+SHIFT			7	NOTE	89	F6	96	59	hh				- Same as MIDI-IN	OFF=0x00, ON=0x7F	
					7	NOTE	72	C5	96	48	hh					OFF=0x00, ON=0x7F	
2		+SHIFT			7	NOTE	96	C7	96	60	hh				- Same as MIDI-IN	OFF=0x00, ON=0x7F	
					7	NOTE	73	C#5	96	49	hh					OFF=0x00, ON=0x7F	
3	BACK	+SHIFT	press		7	NOTE	97	C#7	96	61	hh					- Same as MIDI-IN	OFF=0x00, ON=0x7F
					7	NOTE	101	F7	96	65	hh						OFF=0x00, ON=0x7F
4	LOAD PREPARE	+SHIFT	press		7	NOTE	102	F#7	96	66	hh						OFF=0x00, ON=0x7F
					7	NOTE	103	G7	96	67	hh						OFF=0x00, ON=0x7F
5	USB A	+SHIFT	press		7	NOTE	104	G#7	96	68	hh						OFF=0x00, ON=0x7F
					7	NOTE	105	A7	96	69	hh						OFF=0x00, ON=0x7F
6	USB B	+SHIFT	press		7	NOTE	106	A#7	96	6A	hh						OFF=0x00, ON=0x7F
					7	NOTE	107	B7	96	6B	hh						OFF=0x00, ON=0x7F
		+SHIFT			7	NOTE	108	C8	96	6C	hh						OFF=0x00, ON=0x7F
5. PERFORMANCE PAD																	
1	HOT CUE	+SHIFT	press		1/2/3/4	NOTE	27	D#1	9n	1B	hh						OFF=0x00, ON=0x7F
		long press			1/2/3/4	NOTE	105	A7	9n	69	hh						OFF=0x00, ON=0x7F
2	ROLL	+SHIFT	press		1/2/3/4	NOTE	106	A#7	9n	6A	hh						OFF=0x00, ON=0x7F
		long press			1/2/3/4	NOTE	30	F#1	9n	1E	hh						OFF=0x00, ON=0x7F
3	SLICER	+SHIFT	press		1/2/3/4	NOTE	107	B7	9n	6B	hh						OFF=0x00, ON=0x7F
					1/2/3/4	NOTE	108	C8	9n	6C	hh						OFF=0x00, ON=0x7F
4	SAMPLER	+SHIFT	press		1/2/3/4	NOTE	32	G#1	9n	20	hh						OFF=0x00, ON=0x7F
		long press			1/2/3/4	NOTE	109	C#8	9n	6D	hh						OFF=0x00, ON=0x7F
5	PERFORMANCE PAD 1	+SHIFT	press		1/2/3/4	NOTE	34	A#1	9n	22	hh						OFF=0x00, ON=0x7F
		long press			1/2/3/4	NOTE	110	D8	9n	6E	hh						OFF=0x00, ON=0x7F
5	PERFORMANCE PAD 1				in HOT CUE mode	8/9/10/11	NOTE	0	C-1	9p	00	hh			- Same as MIDI-IN		
					in SAVED FLIP mode	8/9/10/11	NOTE	8	G#-1	9p	08	hh			- Same as MIDI-IN		
5	PERFORMANCE PAD 1				in ROLL mode	8/9/10/11	NOTE	16	E0	9p	10	hh			- Same as MIDI-IN		
					in EDIT GRID mode	8/9/10/11	NOTE	24	C1	9p	18	hh			- Same as MIDI-IN		
5	PERFORMANCE PAD 1				in SLICER mode	8/9/10/11	NOTE	32	G#1	9p	20	hh			- Same as MIDI-IN		
					in SAMPLER mode	8/9/10/11	NOTE	40	E2	9p	28	hh			- Same as MIDI-IN		
5	PERFORMANCE PAD 1				in CUELOOP mode	8/9/10/11	NOTE	48	C3	9p	30	hh			- Same as MIDI-IN		MIDI-IN: OFF=0x00, ON=0x7F
					in SAVED LOOP mode	8/9/10/11	NOTE	56	G#3	9p	38	hh			- Same as MIDI-IN		MIDI-OUT: lit in color specified in color number.
5	PERFORMANCE PAD 1				in SLICER LOOP mode	8/9/10/11	NOTE	64	E4	9p	40	hh			- Same as MIDI-IN		(1-64), OFF=0x00 (dimmer)
					in PITCH PLAY mode	8/9/10/11	NOTE	72	C5	9p	48	hh			- Same as MIDI-IN		
5	PERFORMANCE PAD 1				in velocity SAMPLER mode	8/9/10/11	NOTE	80	G#5	9p	50	hh			- Same as MIDI-IN		In VELOCITY SAMPLER mode,
						8/9/10/11	NOTE	88	E6	9p	58	hh			- Same as MIDI-IN		MIDI-IN: 0x00=0x7F
5	PERFORMANCE PAD 1					8/9/10/11	NOTE	96	C7	9p	60	hh			- Same as MIDI-IN		When not pressed :0x00
						8/9/10/11	NOTE	104	G#7	9p	68	hh			- Same as MIDI-IN		When pressed fully: 0x7F
5	PERFORMANCE PAD 1					8/9/10/11	NOTE	112	E8	9p	70	hh			- Same as MIDI-IN		
						8/9/10/11	NOTE	120	C9	9p	78	hh			- Same as MIDI-IN		
5	PERFORMANCE PAD 1					8/9/10/11	NOTE	112	E8	9p	70	hh			- Same as MIDI-IN		
						8/9/10/11	CC	112	-	Bp	70	hh					
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	120	C9	9p	78	hh			- Same as MIDI-IN			
					8/9/10/11	NOTE	1	C#-1	9p	01	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	9	A-1	9p	09	hh			- Same as MIDI-IN			
					8/9/10/11	NOTE	17	F0	9p	11	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	25	C#1	9p	19	hh			- Same as MIDI-IN			
					8/9/10/11	NOTE	33	A1	9p	21	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	41	F2	9p	29	hh			- Same as MIDI-IN			
					8/9/10/11	NOTE	49	C#3	9p	31	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	57	A3	9p	39	hh			- Same as MIDI-IN			MIDI-IN: OFF=0x00, ON=0x7F
					8/9/10/11	NOTE	65	F4	9p	41	hh			- Same as MIDI-IN			MIDI-OUT: lit in color specified in color number.
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	73	C#5	9p	49	hh			- Same as MIDI-IN			(1-64), OFF=0x00 (dimmer)
					8/9/10/11	NOTE	81	A5	9p	51	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	89	F6	9p	59	hh			- Same as MIDI-IN			In VELOCITY SAMPLER mode,
					8/9/10/11	NOTE	97	C#7	9p	61	hh			- Same as MIDI-IN			MIDI-IN: 0x00=0x7F
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	105	A7	9p	69	hh			- Same as MIDI-IN			When not pressed :0x00
					8/9/10/11	NOTE	113	F8	9p	71	hh			- Same as MIDI-IN			When pressed fully: 0x7F
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	121	C#9	9p	79	hh			- Same as MIDI-IN			
					8/9/10/11	NOTE	113	F8	9p	71	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	CC	113	-	Bp	71	hh						
					8/9/10/11	NOTE	121	C#9	9p	79	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	2	D-1	9p	02	hh			- Same as MIDI-IN			
					8/9/10/11	NOTE	10	A#-1	9p	0A	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	18	F#0	9p	12	hh			- Same as MIDI-IN			
					8/9/10/11	NOTE	26	D1	9p	1A	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	34	A#1	9p	22	hh			- Same as MIDI-IN			
					8/9/10/11	NOTE	42	F#2	9p	2A	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	50	D3	9p	32	hh			- Same as MIDI-IN			MIDI-IN: OFF=0x00, ON=0x7F
					8/9/10/11	NOTE	58	A#3	9p	3A	hh			- Same as MIDI-IN			MIDI-OUT: lit in color specified in color number.
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	66	F#4	9p	42	hh			- Same as MIDI-IN			(1-64), OFF=0x00 (dimmer)
					8/9/10/11	NOTE	74	D5	9p	4A	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	82	A#5	9p	52	hh			- Same as MIDI-IN			In VELOCITY SAMPLER mode,
					8/9/10/11	NOTE	90	F#6	9p	5A	hh			- Same as MIDI-IN			MIDI-IN: 0x00=0x7F
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	98	D7	9p	62	hh			- Same as MIDI-IN			When not pressed :0x00
					8/9/10/11	NOTE	106	A#7	9p	6A	hh			- Same as MIDI-IN			When pressed fully: 0x7F
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	114	F#8	9p	72	hh			- Same as MIDI-IN			
					8/9/10/11	NOTE	122	D9	9p	7A	hh			- Same as MIDI-IN			
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	114	F#8	9p	72	hh			- Same as MIDI-IN			
					8/9/10/11	CC	114	-	Bp	72	hh						
5	PERFORMANCE PAD 1	+SHIFT			8/9/10/11	NOTE	122	D9	9p	7A	hh			- Same as MIDI-IN			

	8	PERFORMANCE PAD 4	+SHIFT	press	in HOT CUE mode in SAVED FLIP mode	8/9/10/11 NOTE 3	D#-1	9p	03	hh	- Same as MIDI-IN	MIDI-IN: OFF=0x00, ON=0x7F MIDI-OUT: lit in color specified in color number. (1-64), OFF=0x00 (dimmer) In VELOCITY SAMPLER mode, MIDI-IN: 0x00-0x7F When not pressed :0x00 When pressed fully: 0x7F
			+SHIFT		in ROLL mode in EDIT GRID mode	8/9/10/11 NOTE 11	B-1	9p	0B	hh	- Same as MIDI-IN	
			+SHIFT		in SLICER mode	8/9/10/11 NOTE 35	B1	9p	23	hh	- Same as MIDI-IN	
			+SHIFT		in SAMPLER mode	8/9/10/11 NOTE 43	G2	9p	2B	hh	- Same as MIDI-IN	
			+SHIFT		in CUELOOP mode	8/9/10/11 NOTE 51	D#3	9p	33	hh	- Same as MIDI-IN	
			+SHIFT		in SAVED LOOP mode	8/9/10/11 NOTE 59	B3	9p	3B	hh	- Same as MIDI-IN	
			+SHIFT		in SLICER LOOP mode	8/9/10/11 NOTE 67	G4	9p	43	hh	- Same as MIDI-IN	
			+SHIFT		in PITCH PLAY mode	8/9/10/11 NOTE 75	D#5	9p	4B	hh	- Same as MIDI-IN	
			+SHIFT		in velocity SAMPLER mode	8/9/10/11 NOTE 83	B5	9p	53	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 91	G6	9p	5B	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 99	D#7	9p	63	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 107	B7	9p	6B	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 115	G8	9p	73	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 123	D#9	9p	7B	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 125	-	Bp	73	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 115	G8	9p	73	hh	- Same as MIDI-IN	
	9	PERFORMANCE PAD 5	+SHIFT	press	in HOT CUE mode in SAVED FLIP mode	8/9/10/11 NOTE 4	E-1	9p	04	hh	- Same as MIDI-IN	MIDI-IN: OFF=0x00, ON=0x7F MIDI-OUT: lit in color specified in color number. (1-64), OFF=0x00 (dimmer) In VELOCITY SAMPLER mode, MIDI-IN: 0x00-0x7F When not pressed :0x00 When pressed fully: 0x7F
			+SHIFT		in ROLL mode in EDIT GRID mode	8/9/10/11 NOTE 12	C0	9p	0C	hh	- Same as MIDI-IN	
			+SHIFT		in SLICER mode	8/9/10/11 NOTE 20	G#0	9p	14	hh	- Same as MIDI-IN	
			+SHIFT		in SAMPLER mode	8/9/10/11 NOTE 28	E1	9p	1C	hh	- Same as MIDI-IN	
			+SHIFT		in CUELOOP mode	8/9/10/11 NOTE 36	C2	9p	24	hh	- Same as MIDI-IN	
			+SHIFT		in SAVED LOOP mode	8/9/10/11 NOTE 44	G#2	9p	2C	hh	- Same as MIDI-IN	
			+SHIFT		in SLICER LOOP mode	8/9/10/11 NOTE 52	E3	9p	34	hh	- Same as MIDI-IN	
			+SHIFT		in PITCH PLAY mode	8/9/10/11 NOTE 60	C4	9p	3C	hh	- Same as MIDI-IN	
			+SHIFT		in velocity SAMPLER mode	8/9/10/11 NOTE 68	G#4	9p	44	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 76	E5	9p	4C	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 84	C6	9p	54	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 92	G#6	9p	5C	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 100	E7	9p	64	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 108	C8	9p	6C	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 116	G#8	9p	74	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 124	E9	9p	7C	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 116	G#8	9p	74	hh	- Same as MIDI-IN	
	10	PERFORMANCE PAD 6	+SHIFT	press	in HOT CUE mode in SAVED FLIP mode	8/9/10/11 NOTE 5	F-1	9p	05	hh	- Same as MIDI-IN	MIDI-IN: OFF=0x00, ON=0x7F MIDI-OUT: lit in color specified in color number. (1-64), OFF=0x00 (dimmer) In VELOCITY SAMPLER mode, MIDI-IN: 0x00-0x7F When not pressed :0x00 When pressed fully: 0x7F
			+SHIFT		in ROLL mode in EDIT GRID mode	8/9/10/11 NOTE 13	C#0	9p	0D	hh	- Same as MIDI-IN	
			+SHIFT		in SLICER mode	8/9/10/11 NOTE 21	A0	9p	15	hh	- Same as MIDI-IN	
			+SHIFT		in SAMPLER mode	8/9/10/11 NOTE 29	F1	9p	1D	hh	- Same as MIDI-IN	
			+SHIFT		in CUELOOP mode	8/9/10/11 NOTE 37	C#2	9p	25	hh	- Same as MIDI-IN	
			+SHIFT		in SAVED LOOP mode	8/9/10/11 NOTE 45	A2	9p	2D	hh	- Same as MIDI-IN	
			+SHIFT		in SLICER LOOP mode	8/9/10/11 NOTE 53	F3	9p	35	hh	- Same as MIDI-IN	
			+SHIFT		in PITCH PLAY mode	8/9/10/11 NOTE 61	C#4	9p	3D	hh	- Same as MIDI-IN	
			+SHIFT		in velocity SAMPLER mode	8/9/10/11 NOTE 69	A4	9p	45	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 77	F5	9p	4D	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 85	C#6	9p	55	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 93	A6	9p	5D	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 101	F7	9p	65	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 109	C#8	9p	6D	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 117	A8	9p	75	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 125	F9	9p	7D	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 117	A8	9p	75	hh	- Same as MIDI-IN	
	11	PERFORMANCE PAD 7	+SHIFT	press	in HOT CUE mode in SAVED FLIP mode	8/9/10/11 NOTE 6	F#-1	9p	06	hh	- Same as MIDI-IN	MIDI-IN: OFF=0x00, ON=0x7F MIDI-OUT: lit in color specified in color number. (1-64), OFF=0x00 (dimmer) In VELOCITY SAMPLER mode, MIDI-IN: 0x00-0x7F When not pressed :0x00 When pressed fully: 0x7F
			+SHIFT		in ROLL mode in EDIT GRID mode	8/9/10/11 NOTE 14	D0	9p	0E	hh	- Same as MIDI-IN	
			+SHIFT		in SLICER mode	8/9/10/11 NOTE 22	A#0	9p	16	hh	- Same as MIDI-IN	
			+SHIFT		in SAMPLER mode	8/9/10/11 NOTE 30	F#1	9p	1E	hh	- Same as MIDI-IN	
			+SHIFT		in CUELOOP mode	8/9/10/11 NOTE 38	D2	9p	26	hh	- Same as MIDI-IN	
			+SHIFT		in SAVED LOOP mode	8/9/10/11 NOTE 46	A#2	9p	2E	hh	- Same as MIDI-IN	
			+SHIFT		in SLICER LOOP mode	8/9/10/11 NOTE 54	F#3	9p	36	hh	- Same as MIDI-IN	
			+SHIFT		in PITCH PLAY mode	8/9/10/11 NOTE 62	D4	9p	3E	hh	- Same as MIDI-IN	
			+SHIFT		in velocity SAMPLER mode	8/9/10/11 NOTE 70	A#4	9p	46	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 78	F#5	9p	4E	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 86	D6	9p	56	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 94	A#6	9p	5E	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 102	F#7	9p	66	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 110	D8	9p	6E	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 118	A#8	9p	76	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 126	F#9	9p	7E	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 118	A#8	9p	76	hh	- Same as MIDI-IN	
	12	PERFORMANCE PAD 8	+SHIFT	press	in HOT CUE mode in SAVED FLIP mode	8/9/10/11 NOTE 7	G-1	9p	07	hh	- Same as MIDI-IN	MIDI-IN: OFF=0x00, ON=0x7F MIDI-OUT: lit in color specified in color number. (1-64), OFF=0x00 (dimmer) In VELOCITY SAMPLER mode, MIDI-IN: 0x00-0x7F When not pressed :0x00 When pressed fully: 0x7F
			+SHIFT		in ROLL mode in EDIT GRID mode	8/9/10/11 NOTE 15	D#0	9p	0F	hh	- Same as MIDI-IN	
			+SHIFT		in SLICER mode	8/9/10/11 NOTE 23	B0	9p	17	hh	- Same as MIDI-IN	
			+SHIFT		in SAMPLER mode	8/9/10/11 NOTE 31	G1	9p	1F	hh	- Same as MIDI-IN	
			+SHIFT		in CUELOOP mode	8/9/10/11 NOTE 39	D#2	9p	27	hh	- Same as MIDI-IN	
			+SHIFT		in SAVED LOOP mode	8/9/10/11 NOTE 47	B2	9p	2F	hh	- Same as MIDI-IN	
			+SHIFT		in SLICER LOOP mode	8/9/10/11 NOTE 55	G3	9p	37	hh	- Same as MIDI-IN	
			+SHIFT		in PITCH PLAY mode	8/9/10/11 NOTE 63	D#4	9p	3F	hh	- Same as MIDI-IN	
			+SHIFT		in velocity SAMPLER mode	8/9/10/11 NOTE 71	B4	9p	47	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 79	G5	9p	4F	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 87	D#6	9p	57	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 95	B6	9p	5F	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 103	G7	9p	67	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 111	D#8	9p	6F	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 119	B8	9p	77	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 127	G9	9p	7F	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 119	B8	9p	77	hh	- Same as MIDI-IN	
			+SHIFT			8/9/10/11 NOTE 127	-	Bp	7F	hh	- Same as MIDI-IN	

Group	Fig.	User interface				MIDI assign reference			MIDI-IN (to computer)			MIDI-OUT (from computer)			Details (Data 2)	
		UI name	+SHIFT	Trigger	Condition (mode)	MIDI Channel (Dec)	NOTE / CC	MIDI Data (Data 1)		Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	Status (Hex)	Data 1 (Hex)		Data 2 (Hex)
illumination Control		Loaded (Deck 1)				12	NOTE	0	C-1				98	00	hh	OFF=0x00, ON=0x7F
		Loaded (Deck 2)				12	NOTE	1	C#-1				98	01	hh	OFF=0x00, ON=0x7F
		Loaded (Deck 3)				12	NOTE	2	D-1				98	02	hh	OFF=0x00, ON=0x7F
		Loaded (Deck 4)				12	NOTE	3	D#-1				98	03	hh	OFF=0x00, ON=0x7F
		Play/Pause (Deck 1)				12	NOTE	12	C0				98	0C	hh	OFF=0x00, ON=0x7F
		Play/Pause (Deck 2)				12	NOTE	13	C#0				98	0D	hh	OFF=0x00, ON=0x7F
		Play/Pause (Deck 3)				12	NOTE	14	D0				98	0E	hh	OFF=0x00, ON=0x7F
		Play/Pause (Deck 4)				12	NOTE	15	D#0				98	0F	hh	OFF=0x00, ON=0x7F
		Cue (Deck 1)				12	NOTE	16	E0				98	10	hh	OFF=0x00, ON=0x7F
		Cue (Deck 2)				12	NOTE	17	F0				98	11	hh	OFF=0x00, ON=0x7F
		Cue (Deck 3)				12	NOTE	18	F#0				98	12	hh	OFF=0x00, ON=0x7F
		Cue (Deck 4)				12	NOTE	19	G0				98	13	hh	OFF=0x00, ON=0x7F
Other		General DJ Connect				12	NOTE	9	A-1				98	09	hh	OFF=0x00, ON=0x7F