

DJ Controller

DDJ-FLX4



Firmware Update Guide

Update the firmware using your computer

If you're using rekordbox for iOS/Android, you can update the firmware from your mobile device.

Go to **"Update the firmware using your mobile device"**.


A. Checking the current firmware version of the DDJ-FLX4

1. Connect your DDJ-FLX4 to your PC/Mac using the USB cable.


2. Check the Firmware Version.

- For Mac :

Click Apple menu > [About This Mac] > [System Report] > [Hardware] > [USB] and check the version displayed for the DDJ-FLX4.



- For Windows :
 - 1) Right-click the Start button and select [Device Manager] from the displayed menu.
 - 2) Open [Sound, video and game controllers] > [DDJ-FLX4 Properties] and select [Details] tab.
 - 3) Select [Hardware Ids] from the [Property] drop-down menu.
 - 4) The x part of “USB\VID_2B73&PID_0045&REV_0100” displayed is the firmware version.
(For example, USB\VID_2B73&PID_0045&REV_0100 means the firmware version is 1.00.)



B. Checking the downloaded file

1. Unzip the downloaded file.

- For Mac :

Double-click [DDJ-FLX4_vxxx_MAC.dmg] to mount it.
- For Windows :

Save the downloaded file [DDJ-FLX4_vxxx_WIN.zip] to a folder in any location such as desktop and unzip it.

2. Check the unzipped file.

- For Mac :

Check the following file is included in the extracted [DDJ-FLX4_vxxx_MAC] folder.
[DDJ-FLX4_vxxx.app]
- For Windows :


Check the following file is included in the extracted [DDJ-FLX6_vxxx_MAC] folder.
[DDJFLX4UpdateProgram.exe]
[ddjflx4hid.dll]
[ddjflx4_A_vxxx.bin]
[ddjflx4_B_vxxx.bin]

- ✓ **xxx** is the new version number of the firmware.
- ✓ Depending on your computer settings, the extension such as .exe or .app may not be displayed.

C. Preparing for the update on the DDJ-FLX4

1. Connect the DDJ-FLX4 to your PC/Mac.

Connect the DDJ-FLX4 to your PC/Mac using a USB cable.



D. Updating the firmware through your PC/Mac


Before updating, close all the applications running on your PC/Mac.

1. Open the updater program.

- For Mac :
Double click [DDJ-FLX4_vxxx.app].
- For Windows :
Double click [DDJFLX4UpdateProgram.exe].

2. Select a language.

Select a language you want to use and click "OK".




3. Check the firmware version.

Ensure that the version is **x.xx**. Click “Start”. (The figure below is an example.)

Do not disconnect the USB cable during the update.


Please use an **AC adaptor** to power your laptop during update.



4. During the update.


Please wait until the progress bar reaches to the right end.

While the update is in progress, the level indicator of DDJ-FLX4 blinks.



5. The update process is complete.

If the message below is displayed, click “OK”.



6. Restart the DDJ-FLX4.


After the update is complete, the DDJ-FLX4 will automatically restart.

E. Checking the firmware version

Check the firmware version of the DDJ-FLX4 as described in “**A. Checking the current firmware version of DDJ-FLX4**”. When you find the version you wanted, the firmware update is successfully complete.

Tips : When you fail to update the firmware

If you fail to update, click “Close”, disconnect the USB cable, and start from “**C. Preparing for the update on the DDJ-FLX4**”.




Update the firmware using your mobile device

- ✓ To update the firmware from a mobile device, you'll need rekordbox for iOS/Android.
- ✓ You'll need an internet connection to download the firmware.
- ✓ The battery level of the mobile device should be at least 50%.
- ✓ Firmware updates are supported only through USB connection.

A. Checking the current firmware version of the DDJ-FLX4

1. Connect a USB power adapter, etc. to the USB port (for power supply) and turn on the DDJ-FLX4.
2. Connect your mobile device to the USB port (for device connection) via USB.
3. Check the firmware version.
 - For iOS :

Tap to select [Settings] > [General] > [About] > [DDJ-FLX4]*.



* In some cases, [DJ CONTROLLER] will be displayed.

- For Android :

There is no way to check the version of the DDJ-FLX4.
Go to "**B. Preparing for the update on the DDJ-FLX4**".

B. Preparing for the update on the DDJ-FLX4

1. Turn on the DDJ-FLX4.

Connect a USB power adapter, etc. to the USB port (for power supply) and turn on the DDJ-FLX4.

2. Connect your mobile device to the DDJ-FLX4.

Connect your mobile device to the USB port (for device connection) using the relevant USB cable.



C. Updating the firmware through rekordbox for iOS/Android

1. Start rekordbox for iOS/Android.


Tap the rekordbox icon.

2. Go to the Settings screen.


Tap the rekordbox icon in the center of the screen.



Tap the Settings icon.




Tap the [DDJ-FLX4 settings] to open the settings screen, and tap [Firmware Update].



* If the firmware is already the latest one, the message "Your DDJ-FLX4 firmware is up to date" is displayed.


3. Start the firmware update.

Tap [Update now].



Read the terms of the Software End User License Agreement carefully and if you agree to them, tap [Agree].


* If you do not agree to the contents of the License Agreement, click [Cancel] to cancel the update.



4. During the update


Wait until it reaches 100%.

While the update is in progress, the level indicator of DDJ-FLX4 blinks.



5. The update process is complete.

Tap [OK] when the following screen appears.



6. Restart the DDJ-FLX4.

Unplug the USB cable to turn off the DDJ-FLX4, then plug the USB cable again to turn on the power.

D. Checking the firmware version

Check the firmware version of the DDJ-FLX4 as described in “**A. Checking the current firmware version of DDJ-FLX4**”. When you find the version you wanted, the firmware update is successfully complete.

Tips : When you fail to update the firmware

If you fail to update, disconnect all the USB cables, and start from “**B. Preparing for the update on the DDJ-FLX4**”.

[Reference information]

For information on the supported operating systems, visit the URL below.

rekordbox.com/en/feature/mobile/

The update will take about 2 minutes.

The images may differ from the ways described in this Guide.

About Trademarks and Registered Trademarks

- Pioneer DJ is a trademark of PIONEER CORPORATION and is used under license.
- rekordbox™ is a trademark or registered trademark of AlphaTheta Corporation.
- Mac, OS X and macOS are trademarks of Apple Inc., registered in the U.S. and other countries.
- iOS is a trademark containing Cisco trademark signs in the U.S. and other countries.
- Android, YouTube, Google Play and the Google Play logo are registered trademarks of Google LLC.
- Windows is a registered trademark of Microsoft Corporation in the U.S. and other countries.
- Other product, technology and company names, etc. mentioned herein are trademarks or registered trademarks of their respective owners.

©2025 AlphaTheta Corporation. All rights reserved.

AlphaTheta Corporation

6F, Yokohama i-Mark Place, 4-4-5 Minatomirai, Nishi-ku, Yokohama, Kanagawa 220-0012 Japan