



Firmware for DJM-S11 - CHANGE HISTORY

ver. 1.05 (August 29, 2024 update)

[IMPROVED]

- ✓ Following the Ecodesign Directive (Directive 2009/125/EC) of the European Union, the time needed for the unit to automatically switch off has been changed to 20 minutes when the Power Management function is turned on.

Please note:

- The name of the energy-saving function, (previously called Auto Standby or Auto Power-Off, depending on the model), has now been changed to Power Management.
- To learn more about the Power Management function, see the latest Instruction Manual, which is available online

[FIXED]

- Fixed an issue that in rare cases caused the waveform display to disappear, which occurred when the setting of the input selector switch was changed while connected to Windows/Mac computer.

ver. 1.04 (20 July, 2023 update)

[NEW]

- ✓ Added Mono Split and Cue Fader Reverse functions. (To use them, touch the headphones icon on the Menu screen.)
- ✓ Dual Deck mode for deck 3/4 can be turned on and off by holding down the [SHIFT] and [BACK] buttons at the same time.
- ✓ Touch FX preset values are now saved when turning the unit off/on.

[FIXED]

- ✓ Minor issues have been fixed.

ver. 1.03 (26 November, 2020 update)

[FIXED]

- ✓ Detailed waveform was displayed incorrectly when playing a short track.
- ✓ Unresponsive LCD display when 2 computers are connected.
- ✓ Occasionally unable to control DJ software correctly.

ver. 1.02 (15 October, 2020 update)

[NEW]

- ✓ SHARP setting added to CROSSFADER SMOOTHING.
- ✓ Character scroll function added to the BROWSE screen.
- ✓ DAY MODE added to SCREEN SETTINGS.

[FIXED]

- ✓ Unable to apply the REVERB and SMOOTH ECHO effects at the same time.
- ✓ Occasionally the mixer that uses emoji at the beginning of the crate names, song names, or artist names stops working.