# Pioneer Dj

**DJ MIXER** 

# DJM-S7

**Firmware Update Guide** 

# **Read Before Use**

If Java has not been installed, please download the Java Runtime Environment (JRE) at: <a href="https://java.com">https://java.com</a> and install it on your computer.

#### A. Check the current Firmware Version of DJM-S7

- 1. Connect the DJM-S7 to your computer.
- 2. Launch the Settings Utility.

For Windows:


[Start] menu > [All Programs] > [Pioneer] -> [DJM-S7 Settings Utility]

For Mac OS:

[Application] > [Pioneer] > [DJM-S7] > [DJM-S7 Settings Utility]

3. Check the firmware version.

The firmware version is displayed in the [About] tab.



The firmware version is also shown on the DJM-S7 display at startup.

# B. Download and unzip the update file

1. Unzip the downloaded file.

Save the downloaded file [DJM-S7\_Verxxx.zip] to an arbitrary folder such as desktop and unzip it.

2. Check the unzipped file.

The [DJM-S7\_Verxxx] folder is generated when the file is unzipped.

Please ensure the following files are included in the folder.

[DJM-S7\_UsbDdjUpdaterApp\_vxxx.jar]

✓ xxx is the number of the new firmware version.

# C. Prepare for updating DJM-S7

## 1. Connect the DJM-S7 and a computer.

Connect the DJM-S7 to your computer using a USB cable.

(Connect the USB cable to the [USB-A] port.)

# 2. Activate the update mode.

Press the power button while pressing the [BACK] button and the [PARAMETER1 LEFT] buttons on the left. Once the update mode is activated, the [CLIP] on the level meter flashes.



# D. Update the firmware using a computer

#### 1. Updating procedures

Close all the applications running on the computer before the update.

#### <STEP1> Activate the updater program.


Double click [DJM-S7\_UsbDdjUpdaterApp\_vxxx.jar] to activate the update file.

#### <STEP2> Check the firmware version before updating.

After ensuring that the firmware version is **x.xx**, click on the [Start] button.


Ensure that the power cable and the USB cable are securely connected to DJM-S7 during the update.

Please make sure to use an AC adaptor to power your laptop during the update.




#### The updating process starts.

Please wait until the progress bar reaches to the right end.



## <STEP3> Complete the updating process.

When the update is complete and the message below appears, click the [OK] button.



# E. Check the firmware version Check the firmware version of DJM-S7 as described in [A. Check the current Firmware Version of DJM-S7]. The firmware update is successfully complete when you find the version as you wanted. [Reference information] For information on the supported operating systems, visit the URL below. pioneerdj.com/support/ The images shown in this Guide may not be the same as the current ones. Trademarks and registered trademarks Mac and macOS are trademarks of Apple Inc., registered in the U.S. and other countries and regions. Windows is a trademark or registered trademark of Microsoft Corporation in the U.S. and other countries. Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other product, technology and company names, etc. mentioned herein are trademarks or registered trademarks of their respective owners.