

dj player
PLX-CRSS12

Firmware Update Guide

Read Before Use

If Java has not been installed, please download the Java Runtime Environment (JRE) at: <u>https://java.com</u> and install it on your computer.

A. Check the current Firmware Version of PLX-CRSS12

- 1. Power on the PLX-CRSS12.
- 2. Open the Utility screen.

Press and hold the [DECK/UTILITY] button.

3. Check the firmware version.

The firmware version is displayed on the screen.

B. Download and unzip the update file

1. Unzip the downloaded file.

Save the downloaded file [PLX-CRSS12_Verxxx.zip] to a folder such as desk top and unzip it.

2. Check the unzipped file.

The [PLX-CRSS12_Verxxx] folder is generated when the file is unzipped.

Please ensure the following files are included in the folder.

[PLX-CRSS12_UsbDdjUpdaterApp_vxxx.jar]

xxx is number of the new firmware version.

C. Prepare for updating PLX-CRSS12

1. Connect PLX-CRSS12 and a computer.

Connect PLX-CRSS12 to your computer using a USB cable.

2. Activate the update mode.

Press the power button while pressing the [STEP PITCH] button and the [TEMPO RANGE] buttons. Once the update mode is activated, "UPDATE" is displayed on the screen.



D. Update the firmware using a computer

1. Update procedures

Close all applications running on the computer before the update.

<STEP1> Activate the updater program.

Double click [PLX-CRSS12_UsbDdjUpdaterApp_vxxx.jar] to activate the update file.

<STEP2> Check the firmware version before updating.

After ensuring that the firmware version is **x.xx**, click on the [Start] button.

Ensure that the power cable and the USB cable are securely connected to PLX-CRSS12 during the update.

Be sure to use an AC adaptor to power your laptop during the update.

Updater Program	\times
Updates the version of your PLX-CRSS12 firmware.	
Launch the PLX-CRSS12 in update mode by pressing the power button while pressing the [STEP PITCH] button and the [TEMPO RANGE] button.	
Current Version: Ver. 1.00	
Update Version: Ver. 1.10	
Close Start	

The updating process starts.

Please wait until the progress bar reaches to the right end.

Updater Program	×
Updates the version of your PLX-CRSS12 firmware.	
Please wait for a few moments until the update process is completed.	
35%	

<STEP3> Complete the updating process.

When the firmware update is complete and the message below appears, click the [OK] button.



E. Check the firmware version

- □ Check the firmware version of PLX-CRSS12 as described in [A. Check the current Firmware Version of PLX-CRSS12].
- □ The firmware update is successfully complete when you find the version as you wanted.

[Reference information]

For information on the supported operating systems, visit the URL below. pioneerdj.com/support/

The images shown in this Guide may not be the same as the current ones.

Trademarks and registered trademarks

- Mac and macOS are trademarks of Apple Inc., registered in the U.S. and other countries and regions.
- Windows is a trademark or registered trademark of Microsoft Corporation in the U.S. and other countries.
- Oracle and Java are registered trademarks of Oracle and/or its affiliates.
- Other product, technology and company names, etc. mentioned herein are trademarks or registered trademarks of their respective owners.