

TORAIZ

TORAIZ SQUID Firmware for TORAIZ SQUID – CHANGE HISTORY

Ver.1.10 (24 April 2019 Update)

[NEW]

- ✓ Now compatible with SQUID Manager, the dedicated application to backup SQUID projects, and export / import midi clips.
- ✓ MIDI message settings for Program Change and Bank Select.
- ✓ Delay setting for each track.
- ✓ Note programming for each step using external MIDI devices.
- ✓ [Pattern Set] edit mode.
- ✓ Now able to output MIDI messages received from the MIDI port to the USB port.
- ✓ Added [Euclid Based] as new [Trigger Type] in [Randomizer Settings].
- ✓ Added [Key Based] as new [Pitch Type] in [Randomizer Settings].

[IMPROVED]

- ✓ Keep sequence playback when entering [TIME WARP] mode during sequence playback.
- ✓ Better view and operability in [Chord] mode.
- ✓ Receive MIDI messages of Start/Stop/Continue regardless of [Sync Source] setting.
- ✓ Nudge regardless of [Sync Source] setting.
- ✓ Sequence playback speed can be set at [Pattern Speed] in [Pattern Setting].
- ✓ Rec function from external MIDI devices.

[FIXED]

- ✓ Unable to send Restart command to external devices connected to [DIN SYNC OUT] or [CLOCK OUT].

- ✓ The behavior when [IN Sync Mode] setting is [1 step] or [Gate].
- ✓ Unable to sync when a legacy device (such as TR-808) is connected to [DIN SYNC OUT].