


DDJ-S1

Hardware Diagram for serato DJ



GROUP	NAME	FUNCTION	(+SHIFT)
No.			
TRANSPORT			
1	▶/II	Play/Pause	Stutter
2	CUE	Cue	Previous Track
3	JOG DIAL	top plate	Scratch(Vinyl On) , Pitch Bend(Vinyl Off)
		outer wheel	Pitch Bend
4	TEMPO SLIDER	sync off	Tempo Control
		sync on	Adjust physical position of TEMPO SLIDER
5	SYNC	Sync	Sync Off
6	BRAKING SPEED ADUJST	Braking Adjust(Stop Time Only)	No assign
7	VINYL	Vinyl Mode On/Off	Jog Illumination Change
8	TEMPO RANGE	Tempo Range(8%, 16%, 50%, 100%)	Tempo Reset
9	KEY LOCK	Key Look On/Off	No assign
10	REVERSE	Censor	Reverse
11	SLIP	Slip Mode On/Off	No assign
12	NEEDLE SEARCH	Search	Roll(1/16, 1/8, 1/4, 1/2, 1)
HOT CUE/SAMPLER			
18	SAMPLER MODE	on	Sampler Mode
		off	Hot Cue Mode
HOT CUE MODE			
13	1	Hot Cue 1	Delete Hot Cue 1
14	2	Hot Cue 2	Delete Hot Cue 2
15	3	Hot Cue 3	Delete Hot Cue 3
16	4	Hot Cue 4	Delete Hot Cue 4
17	5	Hot Cue 5	Delete Hot Cue 5
SAMPLER MODE			
13	1	Sample Slot1 Play/Retrigger	Sample Slot1 Stop
14	2	Sample Slot2 Play/Retrigger	Sample Slot2 Stop
15	3	Sample Slot3 Play/Retrigger	Sample Slot3 Stop
16	4	Sample Slot4 Play/Retrigger	Sample Slot4 Stop
17	5	Sample Slot5 Play/Retrigger	Sample Slot5 Stop
LOOP			
19	LOOP IN	Loop In/In Adjust	Grid Set
20	LOOP OUT	Loop Out/Out Adjust	Grid Tap
21	RELOOP/EXIT	Re loop/Exit	Grid Clear
22	LOOP SELECT	Loop Select	Grid Lock
23	AUTO LOOP	rotate	Auto Loop Size Select/Half and Double
		press	Auto Loop On/Off
BROWSE			
24	LOAD	Load	Instant Doubles
25	ROTARY SELECTOR	rotate	Library Scroll
		press	Library Forward
26	BACK	Library Back	Area switch(File, Browse, Prepare, History)
27	LOAD PREPARE	Add Prepare	Library
28	PANEL SELECT/REC	Panel Select	Save Rec
29	CRATES	Crates Panel	Rec
30	FILES	Files Panel	Simple List
31	BROWSE	Browse Panel	Album Art List
32	PREPARE	Prepare Panel	No assign

GROUP	NAME	FUNCTION	(+SHIFT)
No.			
MIXER			
33	TRIM	Input Gain	Same
34	EQ(HI)	EQ(Hi)	Same
35	EQ(MID)	EQ(Mid)	Same
36	EQ(LOW)	EQ(Low)	Same
37	HEADPHONES CUE	Monitor On/Off	Same
38	CH FADER	Channel Fader	Same
39	MASTER LEVEL	Master Out Volume	Same
40	HEADPHONES MIXING	Monitor Balance	Same
41	HEADPHONES LEVEL	Monitor Volume	Same
42	CROSSFADER	Crossfader	Same
43	C.F. REVERSE	Crossfader Reverse	Same
44	CROSSFADER CURVE	Crossfader Curve(3pos.)	Same
45	FADER START	Crossfader Start	Same
EFFECT			
46	FX CH SELECT *1	Deck1 /Deck2/Master	Same
47	EFFECT SELECT	Multi	Effect2 Select
		Single	Parameter3
48	BEATS/PARAMETER *2	Beats	Parameter2
49	LEVEL/DEPTH	Parameter1	Same
50	FX ON/OFF	Multi	Effect1 On/Off
		Single	Effect2 On/Off
51	TAP	Effect Tap/BPM Auto(Long Press)	Effect1 On/Off
OTHER			
52	SHIFT	Shift	-
53	MIC/AUX THRU	Mic/Aux Thru On/Off(GUI)	Same
MIC/AUX			
MIC1			
54	OFF, ON, TALK OVER	MIC1 Off/On/Talk Over	Same
55	LEVEL	MIC1 Volume	Same
56-1	EQ(LOW)	EQ(Low)	Same
56-2	EQ(MID)	EQ(Mid)	Same
56-3	EQ(HI)	EQ(Hi)	Same
MIC2/AUX			
57	INPUT SELECT	MIC2/AUX Select SW	Same
58	OFF/ON/TALK OVER	MIC2 Off/On/Talk Over	Same
59	LEVEL	MIC2 Volume	Same
60-1	EQ(LOW)	EQ(Low)	Same
60-2	EQ(MID)	EQ(Mid)	Same
60-3	EQ(HI)	EQ(Hi)	Same

Notes:

- *1 To be included when the application is upgraded: MODE SELECT/MIC, AUX
- *2 When you want to control beatgrids, please select [Smart sync] in [DJ Preference] from the [SETUP] of Serato DJ.
- Please refer to the Serato DJ manual for details of these functions.