

OPUS-QUAD

Hardware Diagram for rekordbox dj



GROUP	No.	NAME		FUNCTION	+SHIFT	GROUP	No.	NAME		FUNCTION	+SHIFT	
1, DECK	* Functions are the same for both left and right decks.											
	1	JOG	top	Scratch (Vinyl On)	Search	2, EFFECT						
				Pitch bend (Vinyl Off)								
		side		Pitch bend								
	2	TEMPO			Adjust Tempo	3, MIXER						
	3	TEMPO RESET			Tempo Reset	4, BROWSER						
	4	TEMPO RANGE			Tempo Range							
	5	MASTER TEMPO			Master Tempo On/Off							
	6	KEY SYNC			Key Sync On/Off							
	7	JOG ADJUST			Jog Adjust							
	8	SYNC			Sync On/Off							
			press and hold			Instant Doubles						
	9	MASTER			Master							
	10	JOG MODE			Vinyl On/Off							
	11	VINYL SPEED ADJUST			Vinyl Speed Adjust							
	12	DECK SELECT			Select a deck							
	13	TRACK SEARCH			Prev. / Next Track	Memory Cue Call						
	14	DECK QUANTIZE			Deck Quantize On/Off							
	15	HOT CUE A			Set/start playback from Hot Cue A point	Delete Hot Cue A						
	16	HOT CUE B			Set/start playback from Hot Cue B point	Delete Hot Cue B						
	17	HOT CUE C			Set/start playback from Hot Cue C point	Delete Hot Cue C						
	18	HOT CUE D			Set/start playback from Hot Cue D point	Delete Hot Cue D						
	19	HOT CUE E			Set/start playback from Hot Cue E point	Delete Hot Cue E						
	20	HOT CUE F			Set/start playback from Hot Cue F point	Delete Hot Cue F						
	21	HOT CUE G			Set/start playback from Hot Cue G point	Delete Hot Cue G						
	22	HOT CUE H			Set/start playback from Hot Cue H point	Delete Hot Cue H						
	23	SHIFT			Shift							
	24	BEAT LOOP	turn		Adjust Loop size							
			press			Auto Loop On	Reloop					
				during loop			Auto Loop Off					
	25	LOOP IN			Loop in / Loop in adjust							
			press and hold			4 Beat Loop						
	26	LOOP OUT			Loop out / Loop out adjust							
	27	BEAT JUMP			Beat Jump	Beat Jump Beat Value *1						
	28	SLIP REVERSE			Slip Reverse							
	29	CUE			Set/start playback from Cue point, Back Cue							
	30	PLAY/PAUSE			Play / pause							

2, EFFECT				
3, MIXER				
4, BROWSER				
1	Smart Rotary Selector	rotate	Browse (Select track/folder)	Zoom in/out enlarged waveform
		press	Move area (forward)	
		tilt up	Browse (Track/Folder Select)	
		tilt down	Browse (Track/Folder Select)	
		tilt left	Move hierarchy , move area (backward)	
		tilt right	Move area (forward)	
	2	BACK	Move hierarchy, move area (backward)	
3	TAG TRACK/REMOVE		Register to Tag List / cancel registration	Switch Related Tracks Display
4	LOAD	Load a track		
		press twice	Instant Doubles	
5	NEEDLE SEARCH (2DECK/4DECK)		Needle Search	