

OPUS-QUAD

Hardware Diagram for rekordbox



GROUP	No.	NAME	FUNCTION	+SHIFT	GROUP	No.	NAME	FUNCTION	+SHIFT
1, DECK * 機能は左右デッキ共通です。					2, EFFECT				
1, DECK	1	JOG	天面 スクラッチ (Vinyl On) ビッチベンド (Vinyl Off)	Search	3, MIXER				
		側面 ビッチベンド							
	2	TEMPO	テンポ調整	4, BROWSER					
	3	TEMPO RESET	テンポリセット						
	4	TEMPO RANGE	Tempo Range						
	5	MASTER TEMPO	Master Tempo On/Off						
	6	KEY SYNC	Key Sync On/Off						
	7	JOG ADJUST	JOG ADJUST						
	8	BEAT SYNC	Sync On/Off						
		長押し	INSTANT DOUBLES						
	9	MASTER	Master						
	10	JOG MODE	Vinyl On/Off						
	11	VINYL SPEED ADJUST	Vinyl Speed Adjust						
	12	DECK SELECT	DECK切替						
	13	TRACK SEARCH	PREV / NEXT TRACK	MEMORY CUE CALL					
	14	DECK QUANTIZE	Deck Quantize on/off						
	15	HOT CUE A	HOT CUE A設定/再生	Delete HOT CUE A					
	16	HOT CUE B	HOT CUE B設定/再生	Delete HOT CUE B					
	17	HOT CUE C	HOT CUE C設定/再生	Delete HOT CUE C					
	18	HOT CUE D	HOT CUE D設定/再生	Delete HOT CUE D					
	19	HOT CUE E	HOT CUE E設定/再生	Delete HOT CUE E					
	20	HOT CUE F	HOT CUE F設定/再生	Delete HOT CUE F					
	21	HOT CUE G	HOT CUE G設定/再生	Delete HOT CUE G					
	22	HOT CUE H	HOT CUE H設定/再生	Delete HOT CUE H					
	23	SHIFT	Shift						
	24	BEAT LOOP	回す	LOOPサイズ調整	RELOOP				
		押す	AUTO LOOP ON						
			ループ中	AUTO LOOP OFF					
	25	LOOP IN	Loop in / Loop in adjust						
			長押し	4 BEAT Loop					
26	LOOP OUT	Loop out / Loop out adjust							
27	BEAT JUMP	Beat Jump	Beat Jump Beat Value *1						
28	SLIP REVERSE	SLIP Reverse	Reverse						
29	CUE	Cue設定/再生, BackCue							
30	PLAY/PAUSE	再生/一時停止							

* 1 対応拍数 : 1/8, 1/4, 1/2, 1, 2, 4, 8, 16, 32, 64, 128拍。