

XDJ-XZ for rekordbox VIDEO



Group	No.	Name	Action	Function
BROWSE	1	MENU	Press	Open/close rekordbox VIDEO CONTROL window when selecting MEDIA SELECT LINK.
	2	BACK	Press	Close rekordbox VIDEO CONTROL window.
	3	TEXT	PREVIEW ON	Touch Display text in VIDEO display area. Display text in VIDEO master out window.
	4	IMAGE	PREVIEW ON	Touch Display image in VIDEO display area. Display image in VIDEO master out window.
	5	CAMERA	PREVIEW ON	Touch Display live feed from CAMERA in VIDEO display area. Display live feed from CAMERA in VIDEO master out window.
	6	SLIDESHOW	PLAY/PAUSE STOP	Touch Display and start SLIDE SHOW in VIDEO display area. Pause SLIDE SHOW.
	7	AV SYNC		Touch Sync the video cross fader and the audio cross fader or cancel it.
	8	TRANSITION FX		Touch Go to TRANSITION FX selection window.
	9	TRANSITION FX CALL		Touch Call TRANSITION FX (order as listed)
	10	TRANSITION FX RANDOM		Touch Call TRANSITION FX (RANDOM)
	11	TRANSITION FX FAVORITE(1~5)		Touch Call TRANSITION FX set as FAVORITE



Group	No.	Name	Action	Function
BROWSE	1	Rotary Selector	Turn	Move to next/previous page.
	2	BACK	Press	Back to rekordbox CONTROL window.
	3	BACK	Touch	Back to rekordbox VIDEO CONTROL window.
	4	TRANSITION FX select	Touch	Select TRANSITION FX.