

XDJ-XZ

Hardware Diagram for rekordbox dj



GROUP	No.	NAME	FUNCTION	+SHIFT	
1, DECK	*All the functions assigned on the right deck are the same as those on the left deck shown below.				
	1	JOG	platter	Scratch (Vinyl On)	Search
			wheel side	Pitch bend (Vinyl Off)	
	2	TEMPO		Pitch bend	
	3	TEMPO RESET		Tempo control	
	4	MASTER TEMPO		Tempo Reset	
	5	TEMPO RANGE		Master Tempo On/Off	
	6	SYNC		Tempo Range	
			long press	Sync On/Off	
	7	MASTER		INSTANT DOUBLES	
	8	JOG ADJUST		Master	
	9	JOG MODE		JOG ADJUST	
	10	VINYL SPEED ADJUST		Vinyl On/Off	
	11	TRACK SEARCH		Vinyl Speed Adjust	
	12	SEARCH		PREV / NEXT TRACK	
	13	SHIFT		BEAT JUMP (While Play; BEAT JUMP B, While Pause: BEAT JUMP FINE)	
			Press twice	Shift	
	14	REVERSE		Change decks (deck1 ↔ deck3, etc)	
	15	SLIP		Reverse	
	16	4/8 BEAT		SLIP mode On/Off	
			long press	4 BEAT Loop	
	17	LOOP IN		8 BEAT Loop	
			long press	Loop in / Loop in adjust	
	18	LOOP OUT		4 BEAT Loop	
			long press	Loop out / Loop out adjust	
	19	RELOOP/EXIT		ReLoop/Exit	
			During loop playback	CUE/LOOP CALL, FWD	
20	CALL NEXT / 2X		Loop Size Select (Double)		
		During loop playback	CUE/LOOP CALL, REV		
21	DELETE		Loop Size Select (Half)		
22	MEMORY		DELETE		
23	PLAY/PAUSE		MEMORY		
24	CUE		Play/Pause		
25	JOG RING		Set/call cue, Back cue		
26	LOAD		Load tracks		
		Press twice	INSTANT DOUBLES		
27	NEEDLE SEARCH		NEEDLE SEARCH		
2, EFFECT					
3, MIXER					
4, BROWSER					
1	AUX TRIM		SAMPLER volume when AUX SELECT off		
1	Rotary Selector	rotate	Browse(Track/Folder Select)	Enlarged waveform Zoom In/Out	
		press	Jump between panels (forward)		
2	BACK		Jump between tree view/panels (backward)	Switch banks of Tag List/Playlist Palette	
3	TAG TRACK/REMOVE		Add/delete track to/from TAG LIST	Show Related Tracks	
4	TRACK FILTER		TRACK FILTER OPEN/CLOSE		
5	DECK QUANTIZE		Deck Quantize on/off		
6	TIME MODE / AUTO CUE		TIME MODE (REMAINING / ELAPSED TIME)		
		long press	A. Cue On/Off		
7	DECK 1/3 (SHORT CUT)		Change from Deck 1 to/from Deck 3		
8	DECK 2/4 (SHORT CUT)		Change from Deck 2 to/from Deck 4		
5, PERFORMANCE PADS					
1	HOT CUE		HOT CUE	KEY BOARD	
2	BEAT LOOP		BEAT LOOP	KEY SHIFT	
3	SLIP LOOP		PAD FX 1	PAD FX2	
4	BEAT JUMP		BEAT JUMP	SAMPLER	

GROUP	No.	NAME	FUNCTION	+SHIFT	
5, PERFORMANCE PADS	PERFORMANCE PAD A				
		HOT CUE	Set/call Hot Cue A	Delete HOT CUE A	
		BETAT LOOP	1/4 BEAT LOOP	1/4 BEAT LOOP	
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)	
		BEAT JUMP	BEAT JUMP		
		KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE	
		KEY SHIFT	KEY SHIFT		
		PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)	
		SAMPLER	SAMPLER slot1 playback	SAMPLER slot1 pause	
	PERFORMANCE PAD B				
		HOT CUE	Set/call Hot Cue B	Delete HOT CUE B	
		BETAT LOOP	1/2 BEAT LOOP	1/2 BEAT LOOP	
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)	
		BEAT JUMP	BEAT JUMP		
		KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE	
		KEY SHIFT	KEY SHIFT		
		PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)	
		SAMPLER	SAMPLER slot2 playback	SAMPLER slot2 pause	
	PERFORMANCE PAD C				
		HOT CUE	Set/call Hot Cue C	Delete HOT CUE C	
		BETAT LOOP	1 BEAT LOOP	1 BEAT LOOP	
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)	
		BEAT JUMP	BEAT JUMP		
		KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE	
		KEY SHIFT	KEY SHIFT		
		PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)	
		SAMPLER	SAMPLER slot3 playback	SAMPLER slot3 pause	
	PERFORMANCE PAD D				
		HOT CUE	Set/call Hot Cue D	Delete HOT CUE D	
		BETAT LOOP	2 BEAT LOOP	2 BEAT LOOP	
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)	
		BEAT JUMP	BEAT JUMP		
		KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE	
		KEY SHIFT	KEY SHIFT		
		PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)	
		SAMPLER	SAMPLER slot4 playback	SAMPLER slot4 pause	
	PERFORMANCE PAD E				
		HOT CUE	Set/call Hot Cue E	Delete HOT CUE E	
		BETAT LOOP	4 BEAT LOOP	4 BEAT LOOP	
		PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)	
		BEAT JUMP	BEAT JUMP		
		KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE	
		KEY SHIFT	KEY SHIFT		
		PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)	
		SAMPLER	SAMPLER slot5 playback	SAMPLER slot5 pause	
	PERFORMANCE PAD F				
		HOT CUE	Set/call Hot Cue F	Delete HOT CUE F	
		BETAT LOOP	8 BEAT LOOP	8 BEAT LOOP	
	PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)		
	BEAT JUMP	BEAT JUMP			
	KEYBOARD	Select HOT CUE for KEY SHIFT	Delete HOT CUE		
	KEY SHIFT	KEY SHIFT			
	PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)		
	SAMPLER	SAMPLER slot6 playback	SAMPLER slot6 pause		
PERFORMANCE PAD G					
	HOT CUE	Set/call Hot Cue G	Delete HOT CUE G		
	BETAT LOOP	16 BEAT LOOP	16 BEAT LOOP		
	PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)		
	BEAT JUMP	BEAT JUMP			
	KEYBOARD	Select HOT CUE for KEY SHIFT	KEYBOARD Previous Page		
	KEY SHIFT	KEY SHIFT	KEY SHIFT Previous Page		
	PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)		
	SAMPLER	SAMPLER slot7 playback	SAMPLER slot7 pause		
PERFORMANCE PAD H					
	HOT CUE	Set/call Hot Cue H	Delete HOT CUE H		
	BETAT LOOP	32 BEAT LOOP	32 BEAT LOOP		
	PAD FX1	PAD FX1 (page1)	PAD FX1 (page2)		
	BEAT JUMP	BEAT JUMP	BEAT JUMP Next Page		
	KEYBOARD	Select HOT CUE for KEY SHIFT	KEYBOARD Next Page		
	KEY SHIFT	KEY SHIFT	KEY SHIFT Next Page		
	PAD FX2	PAD FX2 (page1)	PAD FX2 (page2)		
	SAMPLER	SAMPLER slot8 playback	SAMPLER slot8 pause		