

DDJ-SX

List of MIDI messages ver. 1.00



[MIDI channel assignment]
MIDI channel is defined as shown below.
0x9* :Note
0xB* :Control Change (CC)

Channel Category	MIDI channel	channel No.
DECK1, MIXER CH1	1	n=0
DECK2, MIXER CH2	2	n=1
DECK3, MIXER CH3	3	n=2
DECK4, MIXER CH4	4	n=3
FX1	5	m=4
FX2	6	m=5
BROWSER, GLOBAL SECTION	7	m=6
PERFORMANCE PAD (DECK1)	8	p=7
PERFORMANCE PAD (DECK2)	9	p=8
PERFORMANCE PAD (DECK3)	10	p=9
PERFORMANCE PAD (DECK4)	11	p=A
MIDI-OUT	12	m=B

1) As a reference for MIDI assign, MIDI message sent from buttons and knobs of this controller are listed in decimal numbers and English scale. Please utilize this reference depending on the notation of your MIDI compatible software.

NOTE is a term used for MIDI to express that a key of a keyboard or a piano is pressed or your finger is released from it. CC is an abbreviation of "Control Change". Control Change is a kind of MIDI message used to communicate many kinds of control information such as sound quality and volume level. English scale uses alphabetical letters of C, D, E, F, G, A and B as well as # to indicate half-tone.

Group	Fig.	User Interface			MIDI assign reference 1)				MIDI-IN (to computer)			MIDI-OUT (from computer)			Details (Data2)
		UI name	+SHIFT	Trigger	Condition (mode)	MIDI Channel (Dec)	NOTE CC	MIDI Data (Data1) (Dec)	(English scale)	Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	Status (Hex)	Data 1 (Hex)	
1, DECK	1(L,R)	PLAY/PAUSE	+SHIFT	press		1/2/3/4 NOTE	11	B-1	9n	0B	hh	← Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)		
	2(L,R)	CUE	+SHIFT	press		1/2/3/4 NOTE	71	B4	9n	47	hh	← Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)		
	3(L,R)	Jog dial (Platter)	+SHIFT	rotate		Vinyl On	1/2/3/4 CC	34	—	Bn	22	hh		Difference count value from when previous operated	
				touch		Vinyl Off	1/2/3/4 CC	35	—	Bn	23	hh		When turned clockwise: Increases from 65(0x41)	
	4(L,R)	TEMPO	+SHIFT	rotate		Vinyl On	1/2/3/4 NOTE	54	F#3	9n	36	hh		When turned counterclockwise: Decreases from 63(0x3F)	
				rotate		Vinyl Off	1/2/3/4 NOTE	103	G7	9n	67	hh		OFF=0(0x00), ON=127(0x7F)	
	5(L,R)	KEYLOCK	+SHIFT	press			1/2/3/4 CC	33	—	Bn	21	hh		Difference count value from when previous operated	
				long press			1/2/3/4 CC	38	—	Bn	26	hh		When turned clockwise: Increases from 65(0x41)	
	6(L,R)	NEEDLE SEARCH	+SHIFT	press			1/2/3/4 CC	0	—	Bn	00	MSB		When turned counterclockwise: Decreases from 63(0x3F)	
				touch			1/2/3/4 CC	32	—	Bn	20	LSB		Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F)	
7(L)	DECK 1	+SHIFT	press			1/2/3/4 CC	5	—	Bn	05	MSB		*"- side : 0		
			press			1/2/3/4 CC	37	—	Bn	25	LSB		*"+ side : 16383		
8(R)	DECK 2	+SHIFT	press			1/2/3/4 NOTE	26	D1	9n	1A	hh	← Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)		
			press			1/2/3/4 NOTE	96	C7	9n	60	hh	← Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)		
9(L)	DECK 3	+SHIFT	press			1/2/3/4 NOTE	28	E1	9n	1C	hh	← Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)		
			press			1/2/3/4 CC	3	—	Bn	03	hh		Min 0(0x00)-Max 127(0x7F)		
10(R)	DECK 4	+SHIFT	press			1/2/3/4 NOTE	67	G4	9n	43	hh		left edge: 0, right edge: 127		
			press			1/2/3/4 CC	40	—	Bn	28	hh		OFF=0(0x00), ON=127(0x7F)		
11(L)	DECK 1	+SHIFT	press			1 NOTE	114	F#8	90	72	hh		Min 0(0x00)-Max 127(0x7F)		
			press			1 NOTE	115	G8	90	73	hh		left edge: 0, right edge: 127		
12(R)	DECK 2	+SHIFT	press			2 NOTE	114	F#8	91	72	hh		OFF=0(0x00), ON=127(0x7F)		
			press			2 NOTE	115	G8	91	73	hh		LED are lit by DDJ-SX or by MIDI-OUT		
13(L)	DECK 3	+SHIFT	press			3 NOTE	114	F#8	92	72	hh		OFF=0(0x00), ON=127(0x7F)		
			press			3 NOTE	115	G8	92	73	hh		LED are lit by DDJ-SX or by MIDI-OUT		
14(R)	DECK 4	+SHIFT	press			4 NOTE	114	F#8	93	72	hh		OFF=0(0x00), ON=127(0x7F)		
			press			4 NOTE	115	G8	93	73	hh		LED are lit by DDJ-SX or by MIDI-OUT		

Group	Fig.	User Interface				MIDI assign reference				MIDI-IN (to computer)			MIDI-OUT (from computer)			Details (Data2)
		UI name	+SHIFT	Trigger	Condition (mode)	MIDI Channel (Dec)	NOTE CC	MIDI Data (Data1)		Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	
								(Dec)	(English scale)							
2. EFFECT	11(L)	DUAL DECK		press		7	NOTE	122	D9	96	7A	hh				OFF=0(0x00), ON=127(0x7F)
	12(R)					7	NOTE	123	D9	96	7B	hh				OFF=0(0x00), ON=127(0x7F)
	13(L,R)	SYNC	+SHIFT	press		1/2/3/4	NOTE	88	E6	9n	58	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	14(L,R)	AUTO LOOP	+SHIFT	press		1/2/3/4	NOTE	92	G#6	9n	5C	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	15(L,R)	LOOP 1/2X	+SHIFT	press		1/2/3/4	NOTE	20	G#0	9n	14	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	16(L,R)	LOOP 2X	+SHIFT	press		1/2/3/4	NOTE	80	G#5	9n	50	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	17(L,R)	LOOP IN	+SHIFT	press		1/2/3/4	NOTE	18	F#0	9n	12	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	18(L,R)	LOOP OUT	+SHIFT	press		1/2/3/4	NOTE	97	C#7	9n	61	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	19(L,R)	VINYL		press		1/2/3/4	NOTE	19	G0	9n	13	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	20(L,R)	CENSOR (REVERSE)	+SHIFT	press		1/2/3/4	NOTE	98	D7	9n	62	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	21(L,R)	SLIP	+SHIFT	press		1/2/3/4	NOTE	16	E0	9n	10	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	22(L,R)	GRID ADJUST	+SHIFT	press		1/2/3/4	NOTE	76	E5	9n	4C	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	23(L,R)	GRID SLIDE	+SHIFT	press		1/2/3/4	NOTE	17	F0	9n	11	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	24(L,R)	SHIFT		press		1/2/3/4	NOTE	77	F5	9n	4D	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	25(L)	PANEL SELECT	+SHIFT	press		1/2/3/4	NOTE	23	B0	9n	17	hh	9n	0D	hh	LED are lit by DDJ-SX or by MIDI-OUT OFF=0(0x00), ON=127(0x7F)
	26(L,R)	TAKEOVER -				1/2/3/4	NOTE	21	A0	9n	15	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	27(L,R)	TAKEOVER +				1/2/3/4	NOTE	56	G#3	9n	38	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)
	1(L)	FX1-1	+SHIFT	rotate		5	CC	2	34	--	B4	02	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
	1(R)	FX2-1	+SHIFT	rotate		5	CC	18	50	--	B4	12	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
	2(L)	FX1-2	+SHIFT	rotate		6	CC	2	34	--	B5	02	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
	2(R)	FX2-2	+SHIFT	rotate		6	CC	18	50	--	B5	12	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
	3(L)	FX1-3	+SHIFT	rotate		5	CC	4	36	--	B4	04	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
	3(R)	FX2-3	+SHIFT	rotate		5	CC	20	52	--	B4	14	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
	4(L)	FX1 BEATS	+SHIFT	rotate		6	CC	4	36	--	B5	04	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
	4(R)	FX2 BEATS	+SHIFT	rotate		6	CC	20	52	--	B5	14	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
	5(L)	FX1-1 ON	+SHIFT	press		5	CC	6	38	--	B4	06	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
	5(R)	FX2-1 ON	+SHIFT	press		6	CC	6	38	--	B5	06	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
6(L)	FX1-2 ON	+SHIFT	press		5	CC	22	54	--	B4	16	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383	
6(R)	FX2-2 ON	+SHIFT	press		6	CC	22	54	--	B5	16	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383	
7(L)	FX1-3 ON	+SHIFT	press		5	CC	6	38	--	B4	06	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383	
7(R)	FX2-3 ON	+SHIFT	press		6	CC	22	54	--	B5	16	MSB LSB			Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383	
8(L)	FX1 TAP	+SHIFT	press		5	CC	0	--	B4	00	hh				Difference count value from when previous operated Turn clockwise: 1-30(0x01-0x1E) Turn counterclockwise: 127-98(0x7F-0x62)	
8(R)	FX2 TAP	+SHIFT	press		5	CC	16	--	B4	10	hh				Difference count value from when previous operated Turn clockwise: 1-30(0x01-0x1E) Turn counterclockwise: 127-98(0x7F-0x62)	
9	FX1 assign	+SHIFT	press		5	NOTE	67	G4	94	43	hh				OFF=0x00, ON=0x7F	
10		+SHIFT	press		5	NOTE	64	E4	94	40	hh				OFF=0x00, ON=0x7F	
11	FX2 assign	+SHIFT	press		6	CC	0	--	B5	00	hh				Difference count value from when previous operated Turn clockwise: 1-30(0x01-0x1E) Turn counterclockwise: 127-98(0x7F-0x62)	
12		+SHIFT	press		6	CC	16	--	B5	10	hh				Difference count value from when previous operated Turn clockwise: 1-30(0x01-0x1E) Turn counterclockwise: 127-98(0x7F-0x62)	
13	FX2 assign	+SHIFT	press		6	NOTE	67	G4	95	43	hh				OFF=0(0x00), ON=127(0x7F)	
14		+SHIFT	press		6	NOTE	64	E4	95	40	hh				OFF=0(0x00), ON=127(0x7F)	
15	FX2 assign	+SHIFT	press		5	NOTE	71	B4	94	47	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
16		+SHIFT	press		5	NOTE	99	D#7	94	63	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		6	NOTE	71	B4	95	47	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		6	NOTE	99	D#7	95	63	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		5	NOTE	72	C5	94	48	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		5	NOTE	100	E7	94	64	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		6	NOTE	72	C5	95	48	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		6	NOTE	100	E7	95	64	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		5	NOTE	101	F7	94	65	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		5	NOTE	73	C#5	94	49	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		6	NOTE	73	C#5	95	49	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		6	NOTE	101	F7	95	65	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		5	NOTE	74	D5	94	4A	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		5	NOTE	102	F#7	94	66	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		6	NOTE	74	D5	95	4A	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		6	NOTE	102	F#7	95	66	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		7	NOTE	76	E5	96	4C	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		7	NOTE	112	E8	96	70	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		7	NOTE	77	F5	96	4D	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		7	NOTE	113	F8	96	71	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		7	NOTE	78	F#5	96	4E	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		7	NOTE	114	F#8	96	72	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		7	NOTE	79	G5	96	4F	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		7	NOTE	115	G8	96	73	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		7	NOTE	80	G#5	96	50	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		7	NOTE	84	C6	96	54	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		7	NOTE	81	A5	96	51	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		7	NOTE	85	C#6	96	55	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		7	NOTE	82	A#5	96	52	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		7	NOTE	86	D6	96	56	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
	FX2 assign	+SHIFT	press		7	NOTE	83	B5	96	53	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	
		+SHIFT	press		7	NOTE	87	D#6	96	57	hh	-- Same as MIDI-IN			OFF=0(0x00), ON=127(0x7F)	

Group	Fig.	User Interface				MIDI assign reference				MIDI-IN (to computer)			MIDI-OUT (from computer)			Details (Data2)	
		UI name	+SHIFT	Trigger	Condition (mode)	MIDI Channel (Dec)	NOTE CC	MIDI Data (Data1)		Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	Status (Hex)	Data 1 (Hex)	Data 2 (Hex)		
								(Dec)	(English scale)								
3, MIXER	17	FILTER		rotate		7	CC	23	55	—	B6	17	37	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383	
						7	NOTE	116	G#8	96	74	hh	OFF=0(0x00), ON=127(0x7F) Send Note On if the location is other than the center. Send Note Off if the location is the center.				
	18		rotate		7	CC	24	56	—	B6	18	38	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383		
					7	NOTE	117	A8	96	75	hh	OFF=0(0x00), ON=127(0x7F) Send Note On if the location is other than the center. Send Note Off if the location is the center.					
	19		rotate		7	CC	25	57	—	B6	19	39	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383		
					7	NOTE	118	A#8	96	76	hh	OFF=0(0x00), ON=127(0x7F) Send Note On if the location is other than the center. Send Note Off if the location is the center.					
	20		rotate		7	CC	32	64	—	B6	20	40	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383		
					7	NOTE	118	B8	96	77	hh	OFF=0(0x00), ON=127(0x7F) Send Note On if the location is other than the center. Send Note Off if the location is the center.					
3, MIXER	1	Crossfader		slide		7	CC	31	63	—	B6	1F	3F	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) left edge: 0, right edge: 16383	
	2	Channel fader	+SHIFT	slide		1/2/3/4	CC	19	51	—	Bn	13	33	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) bottom end: 0, top end: 16383	
						1/2/3/4	NOTE	102	F#7	9n	66	hh	PLAY message only for CH fader start OFF=0(0x00), ON=127(0x7F)				
						1/2/3/4	NOTE	81	A5	9n	51	hh	SYNC message only for CH fader start OFF=0(0x00), ON=127(0x7F)				
	2	Channel fader	+SHIFT	slide			1/2/3/4	NOTE	82	A#5	9n	52	hh	hh	hh	CUE message only for CH fader start OFF=0(0x00), ON=127(0x7F)	
							1/2/3/4	CC	4	36	—	Bn	04	24	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
							1/2/3/4	CC	7	39	—	Bn	07	27	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383
	5	EQ MID		rotate		1/2/3/4	CC	11	43	—	Bn	0B	2B	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383	
	6	EQ LOW		rotate		1/2/3/4	CC	15	47	—	Bn	0F	2F	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383	
	7	CUE (Headphone)		press		1/2/3/4	NOTE	84	C6	9n	54	hh	—	—	—	Use when INPUT Selector is "PC" OFF=0(0x00), ON=127(0x7F)	
	9	MASTER CUE	+SHIFT	press		1/2/3/4	NOTE	104	G#7	9n	68	hh	—	—	—	OFF=0(0x00), ON=127(0x7F)	
						7	NOTE	99	D#7	96	63	hh	—	—	—	OFF=0(0x00), ON=127(0x7F)	
	10	Crossfader Assign		slide			7	NOTE	98	D7	96	62	hh	—	—	—	OFF=0(0x00), ON=127(0x7F)
							1/2/3/4	NOTE	22	A#0	9n	16	7F	—	—	—	OFF=0(0x00), ON=127(0x7F)
1/2/3/4							NOTE	29	F1	9n	1D	00	—	—	—	OFF=0(0x00), ON=127(0x7F)	
1/2/3/4							NOTE	22/24	A#0/C1	9n	16/18	00	—	—	—	OFF=0(0x00), ON=127(0x7F)	
1/2/3/4							NOTE	29	F1	9n	1D	7F	—	—	—	OFF=0(0x00), ON=127(0x7F)	
12	Channel Level Indicator					1/2/3/4	NOTE	24	C1	9n	18	7F	—	—	—	OFF=0(0x00), ON=127(0x7F)	
						1/2/3/4	NOTE	29	F1	9n	1D	00	—	—	—	OFF=0(0x00), ON=127(0x7F)	
14	SAMPLER VOLUME	+SHIFT	slide		1/2/3/4	CC	3	35	—	B6	03	23	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) bottom end: 0, top end: 16383		
					7	CC	105	—	B6	69	hh	Min 0(0x00)-Max 127(0x7F) bottom end: 0, top end: 127					
4, FRONT PANEL	1	Crossfader curve		rotate		7	CC	1	33	—	B6	01	21	MSB	LSB	Min 0(MSB:0x00 LSB:0x00)-Max 16383(MSB:0x7F LSB:0x7F) When turned fully counterclockwise: 0 When turned fully clockwise: 16383	
	2	INPUT SELECT		slide		1/2/3/4	NOTE	25	C#1	9n	19	hh	—	—	—	PC: OFF=0(0x00) MIC/CD/PHONO/LINE: ON=127(0x7F)	
5, BROWSER	1	Rotary Selector	+SHIFT	rotate		7	CC	64	—	B6	40	hh	—	—	—	Difference count value from when previous operated Turn clockwise: 1-30(0x01-0x1E) Turn counterclockwise: 127-98(0x7F-0x62)	
						7	CC	100	—	B6	64	hh	—	—	—	—	—
						7	NOTE	65	F4	96	41	hh	—	—	—	—	OFF=0(0x00), ON=127(0x7F)
	2		+SHIFT	press		7	NOTE	66	F#4	96	42	hh	—	—	—	OFF=0(0x00), ON=127(0x7F)	
						7	NOTE	70	A#4	96	46	hh	—	—	—	—	LED are lit by DDJ-SX or by MIDI-OUT OFF=0(0x00), ON=127(0x7F)
	3		+SHIFT	press		7	NOTE	88	E6	96	58	hh	—	—	—	OFF=0(0x00), ON=127(0x7F)	
						7	NOTE	71	B4	96	47	hh	—	—	—	—	LED are lit by DDJ-SX or by MIDI-OUT OFF=0(0x00), ON=127(0x7F)
	4		+SHIFT	press		7	NOTE	89	F6	96	59	hh	—	—	—	OFF=0(0x00), ON=127(0x7F)	
						7	NOTE	72	C5	96	48	hh	—	—	—	—	LED are lit by DDJ-SX or by MIDI-OUT OFF=0(0x00), ON=127(0x7F)
	5		+SHIFT	press		7	NOTE	96	C7	96	60	hh	—	—	—	OFF=0(0x00), ON=127(0x7F)	
						7	NOTE	73	C#5	96	49	hh	—	—	—	—	LED are lit by DDJ-SX or by MIDI-OUT OFF=0(0x00), ON=127(0x7F)
	6	BACK	+SHIFT	press		7	NOTE	97	C#7	96	61	hh	—	—	—	OFF=0(0x00), ON=127(0x7F)	
						7	NOTE	101	F7	96	65	hh	—	—	—	—	OFF=0(0x00), ON=127(0x7F)
	7	LOAD PREPARE	+SHIFT	press		7	NOTE	102	F#7	96	66	hh	—	—	—	OFF=0(0x00), ON=127(0x7F)	
7						NOTE	103	G7	96	67	hh	—	—	—	—	OFF=0(0x00), ON=127(0x7F)	
7	LOAD PREPARE	+SHIFT	press		7	NOTE	104	G#7	96	68	hh	—	—	—	OFF=0(0x00), ON=127(0x7F)		
					7	NOTE	104	G#7	96	68	hh	—	—	—	—	OFF=0(0x00), ON=127(0x7F)	

Group	Fig.	User Interface				MIDI assign reference				MIDI-IN (to computer)			MIDI-OUT (from computer)			Details (Data2)
		UI name	+SHIFT	Trigger	Condition (mode)	MIDI Channel (Dec)	NOTE CC	MIDI Data (Data1)		Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	
								(Dec)	(English scale)							
6, PERFORMANCE PADS HOT CUE ROLL SLICER SAMPLER GROUP1-4	1(L,R)	Performance pads 1	+SHIFT	press	in HOT CUE mode	8/9/10/11	NOTE 0	C-1	9p	00	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)			
					8/9/10/11	NOTE 8	G#-1	9p	08	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)				
					in ROLL mode	8/9/10/11	NOTE 16	E0	9p	10	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)			
					8/9/10/11	NOTE 24	C1	9p	18	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)				
					in SLICER mode	8/9/10/11	NOTE 32	G#1	9p	20	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)			
					8/9/10/11	NOTE 40	E2	9p	28	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)				
					8/9/10/11	NOTE 48	C3	9p	30	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)				
					in SAMPLER mode	8/9/10/11	CC 48	--	Bp	30	hh		Min 0(0x00)-Max 127(0x7F) When not pressed : 0 When pressed fully : 127			
					8/9/10/11	NOTE 56	G#3	9p	38	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)				
					in GROUP1 mode	8/9/10/11	NOTE 64	E4	9p	40	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)			
					8/9/10/11	NOTE 72	C5	9p	48	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)				
					in GROUP2 mode	8/9/10/11	NOTE 80	G#5	9p	50	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)			
	8/9/10/11	NOTE 88	E6	9p	58	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
	in GROUP3 mode	8/9/10/11	NOTE 96	C7	9p	60	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)							
	8/9/10/11	NOTE 104	G#7	9p	68	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
	8/9/10/11	NOTE 112	E8	9p	70	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
	in GROUP4 mode	8/9/10/11	CC 112	--	Bp	70	hh		Min 0(0x00)-Max 127(0x7F) When not pressed : 0 When pressed fully : 127							
	8/9/10/11	NOTE 120	C9	9p	78	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
	8/9/10/11	NOTE 1	C#-1	9p	01	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
	8/9/10/11	NOTE 9	A-1	9p	09	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
	8/9/10/11	NOTE 17	F0	9p	11	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
	8/9/10/11	NOTE 25	C#1	9p	19	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
	8/9/10/11	NOTE 33	A1	9p	21	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
	8/9/10/11	NOTE 41	F2	9p	29	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
8/9/10/11	NOTE 49	C#3	9p	31	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in SAMPLER mode	8/9/10/11	CC 49	--	Bp	31	hh		Min 0(0x00)-Max 127(0x7F) When not pressed : 0 When pressed fully : 127								
8/9/10/11	NOTE 57	A3	9p	39	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in GROUP1 mode	8/9/10/11	NOTE 65	F4	9p	41	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
8/9/10/11	NOTE 73	C#5	9p	49	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in GROUP2 mode	8/9/10/11	NOTE 81	A5	9p	51	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
8/9/10/11	NOTE 89	F6	9p	59	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in GROUP3 mode	8/9/10/11	NOTE 97	C#7	9p	61	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
8/9/10/11	NOTE 105	A7	9p	69	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 113	F8	9p	71	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in GROUP4 mode	8/9/10/11	CC 113	--	Bp	71	hh		Min 0(0x00)-Max 127(0x7F) When not pressed : 0 When pressed fully : 127								
8/9/10/11	NOTE 121	C#9	9p	79	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 2	D-1	9p	02	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 10	A#-1	9p	0A	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 18	F#0	9p	12	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 26	D1	9p	1A	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 34	A#1	9p	22	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 42	F#2	9p	2A	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 50	D3	9p	32	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in SAMPLER mode	8/9/10/11	CC 50	--	Bp	32	hh		Min 0(0x00)-Max 127(0x7F) When not pressed : 0 When pressed fully : 127								
8/9/10/11	NOTE 58	A#3	9p	3A	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in GROUP1 mode	8/9/10/11	NOTE 66	F#4	9p	42	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
8/9/10/11	NOTE 74	D5	9p	4A	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 81	A#5	9p	52	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 90	F#6	9p	5A	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 98	D7	9p	62	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 106	A#7	9p	6A	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 114	F#8	9p	72	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in GROUP4 mode	8/9/10/11	CC 114	--	Bp	72	hh		Min 0(0x00)-Max 127(0x7F) When not pressed : 0 When pressed fully : 127								
8/9/10/11	NOTE 122	D9	9p	7A	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 3	D#-1	9p	03	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 11	B-1	9p	0B	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 19	G0	9p	13	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 27	D#1	9p	1B	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 35	B1	9p	23	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 43	G2	9p	2B	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 51	D#3	9p	33	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in SAMPLER mode	8/9/10/11	CC 51	--	Bp	33	hh		Min 0(0x00)-Max 127(0x7F) When not pressed : 0 When pressed fully : 127								
8/9/10/11	NOTE 59	B3	9p	3B	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in GROUP1 mode	8/9/10/11	NOTE 67	G4	9p	43	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
8/9/10/11	NOTE 75	D#5	9p	4B	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 83	B5	9p	53	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 91	G6	9p	5B	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 99	D#7	9p	63	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 107	B7	9p	6B	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 115	G8	9p	73	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in GROUP4 mode	8/9/10/11	CC 115	--	Bp	73	hh		Min 0(0x00)-Max 127(0x7F) When not pressed : 0 When pressed fully : 127								
8/9/10/11	NOTE 123	D#9	9p	7B	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 4	E-1	9p	04	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 12	C0	9p	0C	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 20	G#0	9p	14	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 28	E1	9p	1C	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 36	C2	9p	24	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 44	G#2	9p	2C	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 52	E3	9p	34	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in SAMPLER mode	8/9/10/11	CC 52	--	Bp	34	hh		Min 0(0x00)-Max 127(0x7F) When not pressed : 0 When pressed fully : 127								
8/9/10/11	NOTE 60	C4	9p	3C	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in GROUP1 mode	8/9/10/11	NOTE 68	G#4	9p	44	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)								
8/9/10/11	NOTE 76	E5	9p	4C	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 84	C6	9p	54	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 92	G#6	9p	5C	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 100	E7	9p	64	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 108	C8	9p	6C	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
8/9/10/11	NOTE 116	G#8	9p	74	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									
in GROUP4 mode	8/9/10/11	CC 116	--	Bp	74	hh		Min 0(0x00)-Max 127(0x7F) When not pressed : 0 When pressed fully : 127								
8/9/10/11	NOTE 124	E9	9p	7C	hh	-- Same as MIDI-IN	OFF=0(0x00), ON=127(0x7F)									

Group	Fig.	User Interface				MIDI assign reference				MIDI-IN (to computer)			MIDI-OUT (from computer)			Details (Data2)
		UI name	+SHIFT	Trigger	Condition (mode)	MIDI Channel (Dec)	NOTE CC	MIDI Data (Data1)		Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	
								(Dec)	(English scale)							
6(L,R)	Performance pads 6		+SHIFT	press	in HOT CUE mode	8/9/10/11	NOTE 5	F-1	9p	05	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)		
					8/9/10/11	NOTE 13	C#0	9p	0D	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 21	A0	9p	15	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 29	F1	9p	1D	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 37	C#2	9p	25	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 45	A2	9p	2D	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 53	F3	9p	35	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	CC 53	---	Bp	35	hh			Min 0(x00)-Max 127(0x7F) When not pressed : 0 When pressed fully: 127			
					8/9/10/11	NOTE 61	C#4	9p	3D	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 69	A4	9p	45	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 77	F5	9p	4D	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 85	C#6	9p	55	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 93	A6	9p	5D	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 101	F7	9p	65	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 109	C#8	9p	6D	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
					8/9/10/11	NOTE 117	A8	9p	75	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)			
8/9/10/11	CC 117	---	Bp	75	hh			Min 0(x00)-Max 127(0x7F) When not pressed : 0 When pressed fully: 127								
8/9/10/11	NOTE 126	F9	9p	7D	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 6	F#-1	9p	06	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 14	D0	9p	0E	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 22	A#0	9p	0F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 30	F#1	9p	1E	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 38	D2	9p	26	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 46	A#2	9p	2E	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 54	F#3	9p	36	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	CC 54	---	Bp	36	hh			Min 0(x00)-Max 127(0x7F) When not pressed : 0 When pressed fully: 127								
8/9/10/11	NOTE 62	D4	9p	3E	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 70	A#4	9p	46	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 78	F#5	9p	4E	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 86	D#6	9p	56	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 94	A#6	9p	5E	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 102	F#7	9p	66	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 110	D8	9p	6E	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 118	A#8	9p	76	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	CC 118	---	Bp	76	hh			Min 0(x00)-Max 127(0x7F) When not pressed : 0 When pressed fully: 127								
8/9/10/11	NOTE 126	F#9	9p	7E	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 7	G-1	9p	07	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 15	D#0	9p	0F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 23	B0	9p	17	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 31	G1	9p	1F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 39	D#2	9p	27	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 47	B2	9p	2F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 55	G3	9p	37	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	CC 55	---	Bp	37	hh			Min 0(x00)-Max 127(0x7F) When not pressed : 0 When pressed fully: 127								
8/9/10/11	NOTE 63	D#4	9p	3F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 71	B4	9p	47	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 79	G5	9p	4F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 87	D#6	9p	57	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 95	B6	9p	5F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 103	G7	9p	67	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 111	D#8	9p	6F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	NOTE 119	B8	9p	77	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
8/9/10/11	CC 119	---	Bp	77	hh			Min 0(x00)-Max 127(0x7F) When not pressed : 0 When pressed fully: 127								
8/9/10/11	NOTE 127	G9	9p	7F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 27	D#1	9n	1B	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 105	A7	9n	69	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 30	F#1	9n	1E	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 107	B7	9n	6B	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 32	G#1	9n	20	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 109	C#8	9n	6D	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 34	A#1	9n	22	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 111	D#8	9n	6F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 35	B1	9n	23	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 65	F4	9n	41	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 36	C2	9n	24	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 1	C#-1	9n	01	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 37	C#2	9n	25	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 2	D-1	9n	02	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 38	D2	9n	26	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 3	D#-1	9n	03	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 39	D#2	9n	27	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 4	E-1	9n	04	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 40	E2	9n	28	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 5	F-1	9n	05	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 41	F2	9n	29	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 6	F#-1	9n	06	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 42	F#2	9n	2A	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 7	G-1	9n	07	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 43	G2	9n	2B	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 8	G#-1	9n	08	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 44	G#2	9n	2C	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 9	A-1	9n	09	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 45	A2	9n	2D	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 122	D9	9n	7A	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 46	A#2	9n	2E	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 123	D#9	9n	7B	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 47	B2	9n	2F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 124	E9	9n	7C	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 48	C3	9n	30	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 126	F9	9n	7D	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 49	C#3	9n	31	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 126	F#9	9n	7E	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 50	D3	9n	32	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 127	G9	9n	7F	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 51	D#3	9n	33	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								
1/2/3/4	NOTE 0	C-1	9n	00	hh	---	Same as MIDI-IN	OFF=0(x00), ON=127(0x7F)								

MIDI-OUT

Group	Communication name	Function	MIDI assign reference				MIDI-IN (to computer)			MIDI-OUT (from computer)			Details (Data2)
			MIDI Channel (Dec)	NOTE CC	MIDI Data (Data1)		Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	Status (Hex)	Data 1 (Hex)	Data 2 (Hex)	
					(Dec)	(English scale)							
illumination Control	Loaded (Deck 1)	Trigger for Load illumination	12	NOTE 0	C-1				9B	00	hh	OFF=0x00, ON=0x7F	
	Loaded (Deck 2)		12	NOTE 1	C#-1			9B	01	hh	OFF=0x00, ON=0x7F		
	Loaded (Deck 3)		12	NOTE 2	D-1			9B	02	hh	OFF=0x00, ON=0x7F		
	Loaded (Deck 4)		12	NOTE 3	D#-1			9B	03	hh	OFF=0x00, ON=0x7F		
	Play/Pause (Deck 1)	Control JOG illumination	12	NOTE 12	C0			9B	0C	hh	OFF=0x00, ON=0x7F		
	Play/Pause (Deck 2)		12	NOTE 13	C#0			9B	0D	hh	OFF=0x00, ON=0x7F		
	Play/Pause (Deck 3)		12	NOTE 14	D0			9B	0E	hh	OFF=0x00, ON=0x7F		
	Play/Pause (Deck 4)		12	NOTE 15	D#0			9B	0F	hh	OFF=0x00, ON=0x7F		
	CUE (Deck 1)		12	NOTE 16	E0			9B	10	hh	OFF=0x00, ON=0x7F		
	CUE (Deck 2)		12	NOTE 17	F0			9B	11	hh	OFF=0x00, ON=0x7F		
	CUE (Deck 3)		12	NOTE 18	F#0			9B	12	hh	OFF=0x00, ON=0x7F		
	CUE (Deck 4)		12	NOTE 19	G0			9B	13	hh	OFF=0x00, ON=0x7F		
	Other		DJ App. Connect	12	NOTE 9	A-1			9B	09	hh	connected = 0x00-0x7F(any value)	