



# DDJ-SZ

## Hardware Diagram for Serato DJ



GROUP	No.	NAME	FUNCTION	+SHIFT
<b>1,DECK</b>				
	1	PLAY/PAUSE	Play/Pause	Stutter
	2	CUE	Cue set/play , Cue back	Jump to start of track/Previous track
	3	JOG	<i>platter</i> Scratch (Vinyl on)	Search (Skip mode)
			<i>wheel side</i> Pitch bend (Vinyl off)	
	4	TEMPO	Tempo control	
	5	KEYLOCK	Keylock on/off	Tempo range
			<i>long press</i> Tempo reset	-
	6	NEEDLE SEARCH	Needle search *1	
	7	DECK 1	Select deck 1	-
	8	DECK 2	Select deck 2	-
	9	DECK 3	Select deck 3	-
	10	DECK 4	Select deck 4	-
	11	SYNC	Sync on	Sync off
	12	AUTO LOOP	<i>Loop Off</i> Auto Loop on	Loop active On/Off
			<i>Loop On</i> Auto Loop/Manual Loop off	
	13	LOOP 1/2X	<i>Loop Off</i> Loop size select	Loop shift left
			<i>Loop On</i> Loop half	
	14	LOOP 2X	<i>Loop Off</i> Loop size select	Loop shift right
			<i>Loop On</i> Loop double	
	15	LOOP IN	Loop in/Loop in adjust	Loop slot select
	16	LOOP OUT	Loop out/Loop out adjust	Reloop/Exit
	17	CENSOR (REVERSE)	Slip reverse (momentary)	Reverse
	18	SLIP	Slip mode on/off	Vinyl Mode On/Off
	19	GRID ADJUST	Beat grid adjust	Beat grid set
	20	GRID SLIDE	Beat grid slide	Beat grid clear
	21	SHIFT	Shift	-
	22	PANEL SELECT	[REC]/[FX]/[SP-6] Panel select (forward) *7	[REC]/[FX]/[SP-6] Panel select (back) *7
	23	Takeover Indicator -		
	24	Takeover Indicator +		
	25	STOP TIME	Adjusting the speed at which the track stops from the play mode.	

GROUP	No.	NAME	FUNCTION	+SHIFT
<b>2,EFFECT</b>				
	1	1	<i>SingleFX</i> Single Effect DRY/WET Adjust	-
			<i>MultiFX</i> Multi Effect Parameter1 Adjust	-
	2	2	<i>SingleFX</i> Single Effect Parameter1 Adjust	-
			<i>MultiFX</i> Multi Effect Parameter2 Adjust	-
	3	3	<i>SingleFX</i> Single Effect Parameter2 Adjust	-
			<i>MultiFX</i> Multi Effect Parameter3 Adjust	-
	4	BEATS	<i>SingleFX</i> Effect beats Select	-
			<i>MultiFX</i>	
	5	ON	<i>SingleFX</i> Single Effect on/off	Single Effect Select
			<i>MultiFX</i> Multi Effect1 on/off	Multi Effect1 Select
	6	ON	<i>SingleFX</i> Single Effect parameter1 Select	Single Effect Select
			<i>MultiFX</i> Multi Effect2 on/off	Multi Effect2 Select
	7	ON	<i>SingleFX</i> Single Effect parameter2 Select	Single Effect Select
			<i>MultiFX</i> Multi Effect3 on/off	Multi Effect3 Select
	8	TAP	<i>SingleFX</i> Effect Tap	Single/Multi mode change
			<i>MultiFX</i>	
	9	FX1	FX1 assign on/off	
	10	FX2	FX2 assign on/off	
<b>3,MIXER</b>				
	1	CROSSFADER	Cross Fader(Hardware Control)	Cross Fader Start *2
	2	CH FADER	Channel Fader(Hardware Control)	Channel Fader Start *3
	3	CUE	Headphone monitor on/off(Hardware Control)	Tap BPM
	4	SAMPLER VOLUME	Sampler volume	-
<b>5,BROWSER</b>				
	1	BROWSE	<i>rotate</i> Library Scroll	Library Fast Scroll
			<i>press</i> Load / Library forward	Load From [Files] Panel *11
	2	BACK	Library back	Layout change (VIEW)
	3	LOAD PREPARE	Load to [Prepare] Panel	[Files]/[Browse]/[Prepare]/[History] Panel select (AREA)
	4	USB-A	Using Deck 1 and 3 to control a computer connected to USB-A	-
	5	USB-B	Using Deck 1 and 3 to control a computer connected to USB-B	-
	6	USB-A	Using Deck 2 and 4 to control a computer connected to USB-A	-
	7	USB-B	Using Deck 2 and 4 to control a computer connected to USB-B	-

GROUP	No.	NAME	FUNCTION	+SHIFT		
<b>6,PERFORMANCE PADS</b>						
	1-8	PERFORMANCE PAD	<i>mode</i>			
			<i>HOT CUE</i> Hot cue Set/Play	Hot cue Delete		
			<i>ROLL</i> Loop roll (momentary)			
			<i>SLICER</i> Slicer section Play			
			<i>SAMPLER</i> Sampler slot Play *9	Sampler slot Stop/Load *9 *10		
			<i>CUE LOOP</i> Hot cue : Set Loop / returns to the set loop in point and loop playback / Loop Off	Hot cue: returns to the set loop in point and loop playback		
			<i>SAVED LOOP</i> Loop Slot Loop activate/Loop Off *8	Loop Slot Play		
			<i>SLICER LOOP</i> Slicer section Play			
			<i>VELOCITY SAMPLER</i> Sampler slot Play/Volume *9	Sampler slot Stop/Load *9 *10		
			<i>SAVED FLIP</i> Flip slot Save/Play *6 *9	Flip slot On/Off *6 *9		
			9	HOT CUE	HOT CUE mode / SAVED FLIP mode *4	CUE LOOP mode
				<i>long press</i> QUANTIZE On/Off	-	
	10	ROLL	ROLL mode	SAVED LOOP mode		
	11	SLICER	SLICER mode	SLICER LOOP mode		
	12	SAMPLER	SAMPLER mode	VELOCITY SAMPLER mode		
	13	PARAMETER (◀)	<i>mode</i>			
			<i>HOT CUE</i> Flip Record On/Off *5 *6	Flip Loop On/Off *6		
			<i>SAVED FLIP</i>	-		
			<i>ROLL</i> Loop roll size Select	-		
			<i>SLICER</i> Quantization Select	Domain Select		
			<i>SAMPLER</i> Sampler Bank Select	Sampler Output Select		
			<i>CUE LOOP</i> Loop Half	Loop Shift Left		
			<i>SAVED LOOP</i> Loop Half	Loop Shift Left		
	<i>SLICER LOOP</i> Quantization Select	Domain Select				
	<i>VELOCITY SAMPLER</i> Sampler Bank Select	Sampler Output Select				
	14	PARAMETER (▶)	<i>mode</i>			
			<i>HOT CUE</i> Flip Play *6	Flip On/Off *6		
			<i>SAVED FLIP</i>	-		
			<i>ROLL</i> Loop Roll Size Select	-		
			<i>SLICER</i> Quantization Select	Domain Select		
			<i>SAMPLER</i> Sampler Bank Select	Sampler Output Select		
			<i>CUE LOOP</i> Loop Double	Loop Shift Right		
			<i>SAVED LOOP</i> Loop Double	Loop Shift Right		
	<i>SLICER LOOP</i> Quantization Select	Domain Select				
	<i>VELOCITY SAMPLER</i> Sampler Bank Select	Sampler Output Select				

\*1: If "[NEEDLE SEARCH] pad operation is restricted" is selected in the utilities mode on DDJ-SZ, the search using the [NEEDLE SEARCH] pad can be performed only when you are touching the top of the jog dial or playback is stopped.

\*2: When you use the channel fader start function, [THRU] should be selected in the crossfader assign switch.

\*3: When you use the crossfader start function, [A] or [B] should be selected in the crossfader assign switch.

\*4: When pressing the [HOT CUE] button during HOT CUE mode, SAVED FLIP is enabled.

If you want to go back to HOT CUE mode, press the [HOT CUE] button again.

\*5: Flip record will not begin right after Flip record is enabled.

Only when HOT CUE or CENSOR playback starts after Flip record is enabled, Flip record will begin.

\*6: Available only when Serato Flip is activated and enabled in the [SETUP] menu.

If you do not restart Serato DJ after activating Serato Flip for the first time, some buttons may not respond.

Please make sure to restart Serato DJ once you activate Serato Flip.

\*7: When Serato Flip is activated and enabled in the [SETUP] menu,

the [FLIP] panel can be selected.

\*8: When a Loop is not assigned to a slot, the currently played loop will be saved there.

\*9: Performance Pads 7/8 are not assigned to any function.

\*10:When a Sampler Slot is empty, a track selected in the playlist on Serato DJ will be loaded.

\*11:This feature can be used only with SeratDJ1.7.2 or later versions.

FLIP-related features can be used only with Serato DJ 1.7.0 or later versions. (Serato FLIP is a paid option.)

© 2014 Pioneer Corporation All rights reserved.