

DDJ-200

Hardware Diagram: rekordbox for iOS / Android



Group	No.	Name	Function	+SHIFT
1.DECK				
*All the functions assigned on the right deck are the same as those on the left deck shown below.				
1	JOG DIAL	platter	Scratch	Search
		wheel side	Pitch bend	Pitch bend
2	BEAT SYNC		Beat Sync on/off	Tempo range
3	TEMPO		Tempo control	
4	PLAY/PAUSE		Play/Pause	
5	CUE		Set/Call cue, Back cue	Jump to track start
6	SHIFT		Shift	-

Group	No.	Name	Function	+SHIFT
2.EFFECT				
1	TRANSITION FX		FILTER MIX / SMART FADER on/off	-
3.MIXER				
1	EQ (HI, MID, LOW)		EQ (HI, MID, LOW)	
2	CFX		SOUND COLOR FX parameter (CH1,CH2)	
3	MASTER CUE		Master out monitor on/off	-
4	CUE		Headphone monitor on/off	-
5	CHANNEL FADER		Channel fader	-
6	CROSS FADER		Crossfader	-

Group	No.	Name	Function	+SHIFT
4.PERFORMANCE PADS				
1	PAD 1-8	<i>mode</i>		
		HOT CUE*1	Set/Call Hot Cue	Delete Hot Cue
		BEAT LOOP*2	Auto Beat Loop on/off	
		PAD FX*3	Pad FX on	
		SAMPLER*4	Sampler slot playback	-

*1 The Hot Cue points are set to Performance Pads as follows:

Hot Cue A	Hot Cue B	Hot Cue C	Hot Cue D
Hot Cue E	Hot Cue F	Hot Cue G	Hot Cue H

*2 The number of beats set to the Performance Pads are as follows:

1/4 beat	1/2 beat	1 beat	2 beat
4 beats	8 beats	16 beats	32 beats

*3 Effects are set to the Performance Pads as follows.

Effect 1	Effect 2	Effect 3	Effect 4
Effect 5	Effect 6	Effect 7	Effect 8

*4 Sampler slots are triggered by the Performance Pads as follows:

Slot 1	Slot 2	Slot 3	Slot 4
Slot 5	Slot 6	Slot 7	Slot 8